

6-15KW Lenercom Residential ESS

User's Manual



Thank you for purchasing this product.
Please read this manual before use.
Please keep this manual properly for consultation.

Foreword

Overview

This document mainly introduces the installation, electrical connection, debugging, maintenance and troubleshooting methods of LC-E2 (battery high voltage) Lenercom ESS (hereinafter referred to as “LC-E2”). Please read this manual carefully before installing and using LC-E2 high-voltage products to understand the safety information and the functions and features of LC-E2 high-voltage products.

Scope

This manual is applicable to:

- Installer
- User

Symbols

The following symbols in this manual shall have the meanings as follows.

| Symbol | Description |
|---|--|
|  | To indicate the serious danger which will cause death or serious injury if not avoided |
|  | To indicate the intermediate danger which may cause death or serious injury if not avoided |
|  | To indicate the slight danger which may cause slight or moderate injury if not avoided |
|  | To indicate the warning information for the safety issues about the equipment or environment, if not avoided, which may lead to equipment damage, data loss, performance degradation or other unpredictable results. “Note” does not involve personal injury. |
|  | To highlight the important/key information, best practices, tips, etc. “Description” is not safety warning information, and does not involve any personal, equipment and environmental damage information. |

Version information

| S/N | Revision No. | Revision | Date | Remarks |
|-----|----------------------|--|-----------|---------|
| 1 | V1.0 (first edition) | | 4/11/2022 | |
| 2 | V1.1 (first edition) | 6kW and 15kW three-phase models were added | 5/19/2022 | |
| 3 | | | | |
| 4 | | | | |
| 5 | | | | |

Table of Contents

| | |
|---|----|
| 1 Safety Precautions | 6 |
| 1.1 General safety | 6 |
| 1.2 Personnel requirements | 7 |
| 1.3 Electrical Safety | 8 |
| 1.4 Requirements of installation environment | 9 |
| 1.5 Mechanical safety | 9 |
| 1.6 Debugging safety | 9 |
| 1.7 Maintenance and replacement | 9 |
| 2 Product Introduction | 10 |
| 2.1 Introduction of products | 10 |
| 2.2 Description of appearance and interfaces | 13 |
| 2.2.1 Equipment appearance | 13 |
| 2.2.2 Appearance and interfaces of inverter | 13 |
| 2.2.3 Appearance and interfaces of battery module | 15 |
| 2.3 Label description | 16 |
| 2.4 Working principle | 18 |
| 2.4.1 Block diagram of circuits | 19 |
| 2.4.2 AC/DC coupling | 19 |
| 3 Application and Setting of System Networking | 20 |
| 3.1 System networking mode | 20 |
| 3.2 System application mode and setting | 22 |
| 3.2.1 Self-generating and self-use | 22 |
| 3.2.2 Peak load shifting | 25 |
| 3.2.3 Battery preferred (standby) | 27 |
| 4 Installation of Equipment | 30 |
| 4.1 Check before installation | 30 |
| 4.2 Tools preparation | 31 |
| 4.3 Selection of installation location | 31 |
| 4.4 Space requirements for installation | 32 |
| 4.5 Installation steps | 32 |
| 4.6 Dip settings | 38 |
| 5 Electrical Connection | 40 |
| 5.1 Internal wiring of equipment | 40 |
| 5.1.1 Connection of grounding wire and communication wire | 40 |
| 5.1.2 Power line connection | 41 |
| 5.2 External wiring of equipment | 44 |
| 5.2.1 Inverter grid input and load output wires (single-phase model versus three-phase model) | 44 |
| 5.2.2 PV input wire | 48 |
| 5.2.3 Distribution box wire: | 51 |
| 5.3 Precautions for CT installation: | 55 |
| 5.3.1 CT of single-phase model can be connected to L wire on the grid side. | 55 |

| | |
|---|-----|
| 5.3.2 Installation mode of the three-way camera CT..... | 55 |
| 5.4 Definitions of COM interfaces..... | 56 |
| 5.5 Installation of WiFi data collector..... | 57 |
| 5.5.1 Funtion introduction..... | 57 |
| 5.5.2 Data collector installation..... | 58 |
| 6 Power On/Off..... | 58 |
| 6.1 Power on..... | 58 |
| 6.2 Shutdown:..... | 59 |
| 7 Instructions of APP..... | 60 |
| 7.1 Product Introduction..... | 60 |
| 7.2 APP download..... | 60 |
| 7.3 Functional description..... | 60 |
| 8 Setting..... | 66 |
| 8.1. Control panel..... | 66 |
| 8.2 Description of LED indicator..... | 66 |
| 8.3 Quick setup guide..... | 67 |
| 8.4 Operation method of setting item..... | 68 |
| 8.5 Detailed description of display and setting parameters..... | 69 |
| 8.5.1 Description of parameter information..... | 69 |
| 8.5.2 System setup..... | 73 |
| 8.5.3 Description of setting item:..... | 73 |
| 8.5.4 Battery parameter..... | 76 |
| 8.5.5 Query..... | 81 |
| 8.5.6 Statistics..... | 83 |
| 9 Technical Data..... | 85 |
| 9.1 Parameter list of single-phase model..... | 85 |
| 9.2 Parameter list of three-phase model..... | 89 |
| 9.3 Table of battery module parameters..... | 94 |
| 9.4 Dimensions and weight of equipment..... | 95 |
| 9.5 Dimensions and weight of packaging..... | 95 |
| 10 Transportation..... | 95 |
| 11 Storage..... | 96 |
| 12 Fault Diagnosis..... | 96 |
| 13 Warranty..... | 99 |
| 13.1 Warranty Period..... | 99 |
| 13.2 Warranty Conditions..... | 99 |
| 13.3 Request for Repair..... | 99 |
| 13.4 Faults beyond Warranty Scope..... | 100 |
| 13.5 Service after Expiration of Warranty Period..... | 101 |
| 13.6 Miscellaneous..... | 101 |
| 13.7 Contact Information..... | 102 |

1 Safety Precautions

1.1 General safety

Statement

When installing, operating and maintaining equipment, please read this manual first and follow the identification on the equipment and all safety precautions in this manual.

The "Notes", "Cautions", "Warnings" and "Dangers" in this manual do not represent all safety precautions to be observed, but only serve as supplements to all safety precautions. Lenercom does not assume any responsibility caused by violation of the general safe operation requirements or the safety standards for the design, production and use of equipment. This equipment shall be used in the environment in line with the design specifications, otherwise the equipment fault may be caused, and the resulting equipment abnormality or component damage, personal safety accident, property loss, etc. may not be covered by the quality assurance. When installing, operating and maintaining equipment, please observe the local laws, regulations and specifications. The safety precautions in this manual are only used as a supplement to local laws, regulations and specifications.

Lenercom assumes no responsibility for any of the following situations:

- Operation beyond the conditions of use described in this manual.
- Installation and use environment not in line with relevant international or national standards.
- Unauthorized disassembly, modification of products or modification of software codes.
- Failure to follow the operation instructions and safety warnings of products and documents.
- Equipment damage caused by abnormal natural environment (force majeure, such as earthquake, fire, storm, etc.).
- Damage during the transportation arranged by customer.
- Damage caused by storage conditions inconsistent with the requirements of product documents.

General requirements



Live operation is strictly prohibited during installation.

Do not install, use and operate outdoor equipment and cables (including but not limited to handling equipment, operating equipment and cables, plugging and unplugging signal interfaces connected to outdoors, aerial work, outdoor installation, etc.) in severe weather such as lightning, rain, snow and strong winds above Grade 6.

- After installing the equipment, remove the empty packaging materials in the equipment area, such as cartons, foam, plastics, cable ties, etc.
- In case of fire, withdraw from the building or equipment area and press the fire alarm bell or call the fire emergency number. Under no circumstances is it allowed to re-enter the burning building.

- Do not artificially alter, damage or block the marks and nameplates on the equipment.
- When installing the equipment, use tools to tighten the screws according to the specified torque.
- Fully understand the components, working principle of LC-E2 high-voltage products and relevant standards in the country/region where the project is located.
- Repair the paint scratches during equipment transportation and installation in time which shall not be exposed to outdoor environment for a long time.
- Do not open the back panel of inverter.

Personal safety

In case of the fault that may cause personal injury or equipment damage in the process of equipment operation, terminate the operation immediately, and make report to the person in charge to take effective protective measures.

- Be knowledgeable of the correct use of tools before the use to avoid the personal injury and equipment damage.
- When the equipment is running, the shell temperature is high, and there is a danger of burning. Please do not touch it.

1.2 Personnel requirements

Personnel for the installation and maintenance of LC-E2 high-voltage products shall first receive the rigorous training to understand various safety precautions and correct operation methods.

- Equipment shall only be installed, operated and maintained by the qualified professionals or trained personnel.
- Safety facilities and repair equipment shall only be removed by the qualified professionals.
- Personnel who operate equipment, including operators, trained personnel and professionals, shall have special operation qualifications required by local countries, such as high-voltage operation, working at heights and special equipment operation qualifications.
- Equipment or parts (including software) shall only be replaced by professionals or authorized personnel.



Description

- Professionals: People who have training or experience in operating equipment, and can know all kinds of potential hazard sources and hazard levels in the process of equipment installation, operation and maintenance.
- Trained person: A person with appropriate technical training and necessary experience, who is aware of the danger that may be brought to him when performing an operation, and can take measures to minimize the danger to himself or other personnel.
- Operators: Operators who may come into contact with equipment except trained personnel and professionals.

1.3 Electrical Safety

Grounding requirements

- When installing the equipment to be grounded, install the protective grounding wire first. When removing equipment, remove the protective grounding wire last.
- Do not damage the grounding conductor.
- Do not operate the equipment without installing the grounding conductor.
- Permanently ground the equipment. Before operating the equipment, check the electrical connection of the equipment to ensure that the equipment is reliably grounded.

General requirements



Before the electrical connection, please ensure that the equipment is not damaged, otherwise the electric shock or fire may be caused.

- All electrical connections shall meet the electrical standards of the country/region.
- The grid can be connected for power generation only after the permission is obtained from the power authority of the country/region.
- User-provided cables shall comply with local laws and regulations.
- Special insulating tools shall be used for high voltage operation.

AC/DC operation



Live installation and removal of power line are prohibited. When touching the conductor, the power line core will produce electric arc or spark which can lead to fire or personal injury.

- Before the electrical connection of the equipment, if live parts may be touched, the corresponding breaking device at the front stage of the equipment shall be disconnected.
- Power line label shall be correctly identified before the connection of power line.
- If the equipment has multiple inputs, all inputs of the equipment shall be disconnected, and the equipment can be operated only after the complete power-off.

Wiring requirements

- The insulation layer may be aged and damaged when the cable is used in high temperature environment, and the distance between the cable and the periphery of heating device or heat source area shall be at least 30mm.
- Cables of the same kind shall be bound together, and cables of different kinds shall be laid at the interval of at least 30mm. Winding or cross laying shall be avoided.

1.4 Requirements of installation environment

- Please ensure that the installation environment of equipment is well ventilated.
- When the equipment is running, do not block the vents or heat dissipation system to prevent the fire caused by high temperature.
- Do not place the equipment in the environment of flammable, explosive gas or smoke, and do not carry out any operation in this environment.
- Do not place equipment in high salt spray environment.
- Load strength of installation ground shall be greater than the load caused by product weight.
- The annual temperature of the installation area is lower than 0°C or higher than 50°C.
- Relative humidity of air is less than 95%.

1.5 Mechanical safety

Drilling safety

The following safety precautions shall be considered when drilling holes on walls and ground:

- Wear goggles and protective gloves when drilling holes.
- Shield the equipment during drilling to prevent debris from falling into the equipment. After drilling, clean the debris in time.

Safety of carrying weights

- When carrying weights, prepare for bearing loads to avoid injury.
- When handling equipment, wear protective gloves to avoid injury.

| | |
|---------------------------|------------------------|
| < 18 kg (< 40 lbs) | 1 person |
| 18 ~ 32 kg (40 ~ 70 lbs) | 2 persons |
| 32 ~ 55 kg (70 ~ 121 lbs) | 3 persons |
| > 55 kg (> 121 lbs) | 4 persons or machinery |

1.6 Debugging safety

When the equipment is powered on for the first time, the parameters shall be set correctly by professionals.

1.7 Maintenance and replacement



During the operation, there is high voltage, which may produce electric shock, resulting in death, serious personal injury or property loss. Therefore, the equipment shall be powered off before any

maintenance, which shall be conducted in strict accordance with the safety precautions listed in this manual and other relevant documents.


- Please maintain the equipment after being knowledgeable of this manual and preparing suitable tools and test devices.
- Before the maintenance, please power off the equipment first, and then follow the instructions of the delayed discharge label and wait properly to ensure that the equipment has been powered off before operating the equipment.
- During the maintenance, please prevent the irrelevant personnel from entering the maintenance site, and set the temporary warning signs or fences for isolation.
- If the equipment fails, please contact your dealer for treatment.
- The equipment can be powered on again only after the fault is solved, otherwise the failure may be deteriorated or the equipment may be damaged.

2 Product Introduction

2.1 Introduction of products

Features

LC-E2 products are comprised of PV energy storage hybrid inverter, energy storage battery module and wireless communication module. PV power generation system can be formed if PV is connected. The product mainly functions to convert DC power of PV and battery into AC power and output it to loads. The system, in conjunction with the household EMS (Energy Management System) and BMS (Battery Management System) independently developed by Lenercom, can realize remote data monitoring, early warning and control of LC-E2.



The system can be used in off-grid system and grid-connected system, and is suitable for many applications such as home users, small agriculture, small business and electric vehicle charging.

Model

LC-E2 mainly includes the following models

- Single-phase models:

LC-E2-915S LC-E2-920S LC-E2-925S LC-E2-930S
 LC-E2-1015S LC-E2-1020S LC-E2-1025S LC-E2-1030S
 LC-E2-1115S LC-E2-1120S LC-E2-1125S LC-E2-1130S

● Three-phase models

LC-E2-615T LC-E2-620T LC-E2-625T LC-E2-630T
 LC-E2-815T LC-E2-820T LC-E2-825T LC-E2-830T LC-E2-835T
 LC-E2-1020T LC-E2-1025T LC-E2-1030T LC-E2-1035T
 LC-E2-1225T LC-E2-1230T LC-E2-1235T
 LC-E2-1535T LC-E2-1240T LC-E2-1245T


● Model description (taking LC-E2-1020S and LC-E2-1020T as examples)

| | | | |
|--------------|------------------|------------------|---|
| LC-E2 | 10 | 20 | S/T |
| Product line | Rated power (kW) | Battery capacity | S stands for single-phase T stands for three-phase |

● Description of battery capacity

| Model | No of battery modules | Battery capacity |
|-------|-----------------------|------------------|
| 05 | 1 | 5.12kWh*1 |
| 10 | 2 | 5.12kWh*2 |
| 15 | 3 | 5.12kWh*3 |
| 20 | 4 | 5.12kWh*4 |
| 25 | 5 | 5.12kWh*5 |
| 30 | 6 | 5.12kWh*6 |
| 35 | 7 | 5.12kWh*7 |
| 40 | 8 | 5.12kWh*8 |
| 45 | 9 | 5.12kWh*9 |

LC-E2 configuration
 LC-E2=inverter * 1 + battery module * n + base * 1
 Note: n is the number of battery modules
 Single-phase model: $3 \leq n \leq 7$;
 Three-phase model: $3 \leq n \leq 9$;




- Inverter mainly includes the following models

LC-9KH1
LC-10KH1
LC-11KH1
LC-6KH3
LC-8KH3
LC-10KH3
LC-12KH3
LC-15KH3


- Model description (for examples LC-10KH1 and LC-10KH3)

| LC | 10K | H | 1/3 | |
|--------------|----------------|-------------------------|---|---|
| Product line | Inverter Power | High voltage of battery | 1 stands for single-phase 220Vac 3 stands for three-phase 380Vac |  |

- Battery module mainly includes the following models (for example LC-BH512)


| LC | B | H | 512 | |
|--------------|----------------|-------------------------|--------------------------|--|
| Product line | Battery Module | High voltage of battery | Battery capacity 5.12kWh |  |

Base is as shown in the following figure.




2.2 Description of appearance and interfaces


2.2.1 Equipment appearance



Instruction: Lenercom LC-E2 6-15kW products can accommodate up to 7 battery modules for single-phase model and 9 battery modules for three-phase model. In case of more than 7 battery modules, please contact your dealer or Lenercom.

2.2.2 Appearance and interfaces of inverter





Description


4 channels of PV input for single-phase model, and 2 channels of PV input for three-phase model

| Code | Name | Description | |
|------|---|--|--|
| 1 | Cathode MC4 socket of PV | To connect PV cathode | |
| 2 | Anode MC4 socket of PV | To connect PV anode | |
| 3 | PV switch | To turn on/off PV | |
| 4 | AC inlet/outlet | Grid, generator and load | |
| 5 | DC breaker | Breaker for the connection of battery pack and inverter | |
| 6 | LCD display panel | To display the data and set the functions of inverter | |
| 7 | Grid-connected operation indicator | Green when connected to the grid | See the description of control panel for details |
| 8 | Off-grid operation indicator | Green for off-grid with load | |
| 9 | Alarm indicator | Yellow when an alarm is given | |
| 10 | Fault indicator | Red for serious fault | |
| 11 | Function button | To set the functions | |
| 12 | Communication port | See 5.2.1 “Definitions of inverter communication interfaces” for details | |
| 13 | COM1 | To connect WIFI data collector | |
| 14 | BMS mainframe communication port | BMS mainframe communication connection | |
| 15 | COM2 | Not developed | |
| 16 | Grid-connected grid input/off-grid AC output terminal | Single-phase models: L/N/PE Three-phase models: L1/L2/L3/N/PE | |

| | | |
|----|--------------------------------|----------------------------------|
| 17 | Longitudinal bolt | For installation and positioning |
| 18 | Anode socket | To connect the master anode |
| 19 | Button switch | Start switch of battery |
| 20 | Cathode socket | To connect the master cathode |
| 21 | Button switch | Emergency stop button of battery |
| 22 | BMS battery communication port | BMS battery communication link |
| 23 | Handle | For handling |

2.2.3 Appearance and interfaces of battery module

The interface of battery module is located on the back of battery module. Open the back cover of battery module and you can see it, as shown in the following figure



| Code | Name | Description |
|------|---------------------|--|
| 1 | Front locating hole | Transverse |
| 2 | Rear locating hole | Transverse |
| 3 | Rear locating hole | Longitudinal |
| 4 | Front locating pin | Transverse |
| 5 | Rear locating pin | Transverse |
| 6 | Rear locating pin | Longitudinal |
| 7 | Back panel | Openable |
| 8 | Back panel handle | |
| 9 | Handle | |
| 10 | Indicator | To be blue if the battery module is powered on |
| 11 | Anode socket | To connect the cathode of battery module or |

| | | |
|----|-----------------------------|--|
| | | anode of inverter |
| 12 | Cathode socket | To connect anode of battery module below |
| 13 | Switch of battery module | To power on/off the battery module |
| 14 | Dip switch | For detailed design, please refer to the setting description of dip switch |
| 15 | Grounding point | To connect the grounding point of adjacent battery or inverter |
| 16 | BMS communication interface | To connect BMS communication interface of adjacent battery or inverter |

2.3 Label description

Taking LC-E2-1020T as example:

Inverter nameplate

| Lenercom ESS | |
|--|---------------------|
| Model: LC-E2-1020 T | |
| PV input | |
| Maximum PV input power | 15kW |
| Maximum PV input current | 2*13A |
| PV short circuit current | 2*16A |
| MPPT voltage range | 180~850V |
| MPPT voltage range at full power | 430~850V |
| Maximum PV input voltage | 1000V |
| Quantity of MPPT | 2 |
| Maximum number of strings in parallel of each MPPT | 1 |
| AC output / input (grid-connected) | |
| Rated grid voltage | 3W+N+PE,230/400V |
| Rated grid frequency | 50Hz/60Hz |
| Rated output power | 10000W |
| Maximum grid-connected output apparent power | 11000VA |
| Maximum grid-connected output current | ac,15.9A |
| Maximum grid-connected input apparent power | 22000VA |
| Maximum grid-connected input current | ac,31.9A |
| Power factor | -0.8~+0.8 |
| AC output (off-grid) | |
| Rated off-grid voltage | 3W+N+PE,230/400V |
| Rated off-grid frequency | 50Hz/60Hz |
| Maximum off-grid output apparent power | 11000VA |
| Maximum off-grid output current | ac,15.9A |
| Battery parameters | |
| Input voltage range of battery | 166~233V |
| Rated voltage of battery pack | 204.8V |
| Maximum charge current | 50A |
| Maximum discharge current | 50A |
| Maximum charge / discharge power | 10kW |
| Battery type | LiFePO ₄ |
| System parameters | |
| IP grade | IP20 |
| Dimensions (W*D*H) | 600*420*1750mm |
| Net weight | 299kg |
| Maximum efficiency | 98.2% |
| | |

Battery module nameplate

| Parameters of LC-BH512 battery module | |
|---------------------------------------|------------------------|
| Battery type | Lithium iron phosphate |
| Battery capacity | 100Ah |
| Rated voltage | 51.2V |
| Battery power | 5120Wh |
| | |

Box identification

This section explains all the symbols on the inverter and type labels.

* Symbols on type labels


| Symbol | Description |
|---|--|
|  | CE mark The product meets the requirements of applicable CE product line |
|  | Beware of hot surfaces. The product may get hot during operation to avoid the contact during operation. |
|  | Danger of high-voltage electric shock! |
|  | Watch out! Failure to comply with the warnings in this manual may cause the personal injury |
|  | Please follow the attached manual. |
|  | The inverter and battery shall not be disposed of with household waste, and the disposal information can be found in the attached file. |
|  | Do not operate this inverter until it is isolated from the battery, power supply, and field PV generator. |
|  | Beware of rollover! |
|  | High voltage may endanger life. After the power off, there is residual voltage in the inverter which takes 5 minutes to discharge. Wait 5 minutes before opening the cover. |
|  | TUV Mark This product has obtained TUV certificate |

2.4 Working principle


LC-E2 is connected with a PV string and an energy storage battery, converts the direct current of PV and battery into alternating current and outputs it to the loads. The direct current of PV can charge the battery at the same time. LC-E2 is connected with a AC power supply, bypass the output to the load. At the same time, the inverter can convert the AC input power into DC power to charge the battery.

2.4.1 Block diagram of circuits

Block diagram of single-phase circuit




Block diagram of three-phase circuit



2.4.2 AC/DC coupling

Lenercom LC-E2 can be applied to DC coupling system (mainly newly installed), AC coupling system (mainly retrofit) and hybrid coupling system (mainly retrofit and increased PV capacity)



*DC Coupling
For new installation*

*DC/AC Coupling
For modification and PV capacity expansion*

 Warning: For AC/hybrid coupling systems, two electricity metering units shall be installed.

3 Application and Setting of System Networking


3.1 System networking mode

LC-E2 single-phase/three-phase product networking is mainly used in household, small industrial and commercial enterprises, pure off-grid PV energy storage system. There are two main networking modes:

- Grid and off-grid networking system
- Pure off-grid networking system

Networking 1: LC-E2 system networking


Grid and off-grid energy storage system consists of PV string, LC-E2 energy storage system, load and distribution unit, current transformer, power grid, etc. PV string converts solar energy into electric energy, which is converted to load power supply and fed to power grid through inverter. When the grid is powered off, the equipment automatically switches to off-grid (EPS) mode. At this time, the off-grid load can be used normally, but the grid-connected load cannot be used.



Instruction: the above picture is a single-line schematic diagram which is applicable to single-phase / three-phase systems.


Networking 2: LC-E2 system + PV grid-connected inverter

Grid and off-grid energy storage system supports cascade with PV inverter of any manufacturer to form AC coupling system. Grid input is connected to AC grid-connected end, and off-grid load is connected to LC-E2 system. AC coupling system can effectively solve the problem of remaining power storage of PV. LC-E2 system may not be connected with PV, and can also be directly used for the transformation of original PV system.



Networking 3: LC-E2 system + diesel generator (off-grid)

Grid and off-grid energy storage system supports connection with diesel generator and is used in areas without grid coverage.



3.2 System application mode and setting

LC-E2 energy storage system can provide a variety of working modes according to different requirements.

- Self-generating and self-use
- Peak-valley arbitrage
- Battery preferred (standby)

3.2.1 Self-generating and self-use

Working mode: Self-generating and self-use

PV priority: load > battery > grid

- Suitable for areas with high electricity price, low or no subsidy for Internet access.
- PV supplies power to the load first, and the excess generated power of PV is stored in the battery.

When PV power generation is insufficient or there is no PV power generation at night, the battery discharges for the load, and the gap is supplemented by the power grid. This mode improves the self-use rate of PV system and the self-sufficiency rate of household energy, and saves electricity expenses.

- The working mode is "self-generating and self-use". The default charge cut-off capacity of Lenercom LC-E2 system is

100%, and the discharge cut-off capacity is 10%. If it is necessary to modify the charge or discharge cut-off capacity, refer to 8.3 “Energy Storage Control Settings”.

Instruction: Control [anti-countercurrent] {allowed/prohibited}; factory default setting {forbidden}.

Examples of self-generating and self-use


Examples of self-generating and self-use:

(1) When PV illumination is sufficient, PV input power is 10kW, load consumption is 5kW, and charge power of energy storage system is 5kW.


(2) When PV illumination becomes weak, PV input power is 4kW, load consumption is 8kW, and discharge power of energy storage for load is 4kW.

(3) When there is no illumination, the load consumes 10KW, the energy storage discharges 8KW to the load, and the grid supplies 2KW to the load.


(1)



(2)



(3)




Working mode: Self-generating and self-use, surplus electricity fed to grid

PV priority: load > battery > grid

- Suitable for areas with high electricity price, low or no subsidy for Internet access.
- PV supplies power to the load first, and the surplus generated power of PV is stored in the battery, and the surplus power is connected to the grid. When PV power generation is insufficient or there is no PV power generation at night, the battery discharges for the load, and the gap is supplemented by the power grid. This mode improves the self-use rate of PV system and the self-sufficiency rate of household energy, and saves electricity expenses.

Example of working mode:

When PV illumination is sufficient, PV input power is 10kW, load consumption is 1kW, charge power of energy storage system is 8kW, and discharge to power grid is 1kW.



3.2.2 Peak load shifting


Working mode: peak load shifting

PV priority: Battery > load > grid (charging)

PV priority: Load > battery > grid (discharging)


- It is suitable for large peak-valley price difference.
- The working mode is "peak load shifting", and the charging and discharging period is manually set, for example, the low electricity price period at night is selected for charging, during which the system charges the energy storage system with the maximum charging power, and the high electricity price period is selected for discharging, so the battery can only discharge in the discharging period, thus saving the household electricity cost.
- Up to 3 periods can be set, and the charging and discharging parameters can be set with reference to 8.3 "Energy Storage".
- This mode requires at least one set of charging period and discharging period. In the charging period, power grid is allowed to charge the energy storage system, and in the discharging period, the load can be supplied with power. Energy storage system does not discharge in other periods, and PV and power grid supply power to the load. (In off-grid mode, the grid is powered down and the energy storage system can discharge at any time.)

Example of peak load shifting






Set charging time: 00: 00~06: 00
BAT SOC < Grid charging stop SOC




Non set charging and discharging time period
12: 00~17: 00





Discharge setting time period
17: 30~21: 30



3.2.3 Battery preferred (standby)


Working mode: battery preferred (standby)

PV priority: battery > load > grid

This mode is suitable for areas with frequent power outages. When the grid is disconnected, this mode ensures that the battery has enough energy supply. In this mode, the battery will be charged at the maximum set power and will never discharge when the grid is connected.




BAT SOC < Charging stop SOC






BAT SOC > Charging stop SOC




Power failure of public grid






Power failure of public grid



Power failure of public grid



*** EPS status**

When the grid is off, the system will provide emergency power through PV or battery to power the household load.

4 Installation of Equipment

4.1 Check before installation

Check of external package

Before unpacking the inverter, check the external package for visible damage, such as holes, cracks or other signs of possible internal damage, and check the models of inverter and battery module. In case of any package anomaly or incorrect inverter model, do not open it and contact your dealer as soon as possible.

Check of fittings

Check the following list of parts to ensure no missing part


Lenercom provides the necessary parts for installation in the box, including:

| LC-E2 | | | | |
|---|---|---|--|---|
|  |  |  |  |  |
| M5x12 | Expansion screw | | | |
| 8 screws | 8 x | 4 fixing supports | 1 communication wire of battery (harness) | 2xN+3 grounding wires |
|  |  |  |  |  |
| 1xN series wires of battery | 1 master cathode wire of battery | 1 master anode wire of battery | 1 communication wire of inverter (network cable) | 1 current transformer |

Instruction: "N" is the number of LC-E2 battery modules.

Data collection module has been assembled before its delivery.

4.2 Tools preparation


| Category | | Tools and Instruments | | |
|-------------------------------|---|---|--|--|
| Installation |  |  |  | |
| | Percussion drill (bit ϕ 8mm) | Torque socket spanner | Torque spanner | |
| Category | | Tools and Instruments | | |
| Category name |  |  |  | |
| | Oblique plier | Wire stripping plier | Torque screwdriver | |
| |  |  |  | |
| | Utility knife | Crimping plier (Model: PVCZM-22100/19100) | Multimeter (DC voltage range \geq 600V DC) | |
| |  |  |  | |
| | Removal and installation tools (Model: PVMS-HZ open spanner) | Cable tie | Clip-on ammeter | |
| |  |  | | |
| | Marker pen | Steel tape | | |
| Category | | Tools and Instruments | | |
| Personal protective equipment |  |  |  | |
| | Safety gloves | Protective goggles | Dust mask | |
| |  | | | |
| | Safety shoe | | | |

4.3 Selection of installation location

- The product shall be installed in a well-ventilated indoor environment to ensure good heat dissipation.
- LC-E2 shall not be installed in areas where flammable and explosive materials are stored.
- LC-E2 will be corroded when installed in high salt spray areas, which may cause fire.
- LC-E2 shall not be installed on the flammable building materials.
- LC-E2 is heavy, so the mounting surface shall be firm and can support the inverter.

4.4 Space requirements for installation

The distance between product and surrounding objects shall be more than 50cm to ensure the sufficient heat dissipation and maintenance space as follows:





4.5 Installation steps

Caution


The equipment shall be mounted by no less than 3 installers who shall wear the safety shoes, gloves and other protective tools.

Step 1: Take out inverter, battery, base and accessories;







Step 2: First place the base at the installation position of equipment, take off the back panel of each battery box, and put the first battery box on the




Remove the back panel of battery module




Step 3: Align the transverse locating pin at the bottom of battery box with the axis of transverse locating hole of base; push the battery to the extent that the longitudinal locating pin of battery is aligned with the longitudinal locating hole of base, put down the longitudinal locating pin at the back of battery, and complete the installation after the clamping sound of pin;

In the direction of arrow, push the battery on the left and right sides at the same time to insert the limit post of battery into the limit hole of base.




Rotate and drop two longitudinal locating pins respectively, insert the locating pin into the locating hole and complete the installation after the clamping sound of pin




Description of correct installation: the locating pin is fully inserted into the locating hole





Description of correct installation: the locating pin is fully inserted into the locating hole




Description of wrong installation: Locating pin is not fully inserted into locating hole



Step 5: Install the rest of the batteries and inverters according to the same method and steps as above;







Step 6: Fix the equipment, and after completing all installations and debugging, apply the rear cover of battery box, install two fixing supports on the back of inverter, punch two expansion screws on the wall according to the height of screw holes of the fixing support, move the equipment against the wall, and lock the fixing support on the expansion screw;



Equipment shall be installed by not less than 3 installers who shall wear safety shoes, gloves and other protective tools.




The expansion screws are fixed on the wall



Step 7: Lock the universal wheel


After fixing the equipment, lock the universal wheel according to the following figure:



4.6 Dip settings

After the installation, set the communication address of battery BMS. The dip switch for address setting is located on the left side of BMS interface on the back of battery module as shown in the following figure.

Schematic diagram of dip switch:



Instruction: The dip switch is actually inverted, and the digital dip position shall be checked for dipping.




6-15kW products can accommodate up to 7 battery modules for single-phase model and 9 battery modules for three-phase model. In case of more than 7 battery modules, please contact your dealer or Lenercom

Dip switch is used to set the address of each BMS slave protection board. The code value is "1" at "ON" position, and "0" at "OFF" position.

The list of dip addresses is as follows:

| Dip position | | | | Address |
|--------------|---|---|---|---------|
| 4 | 3 | 2 | 1 | |
| 0 | 0 | 0 | 0 | 0 |
| 0 | 0 | 0 | 1 | 1 |
| 0 | 0 | 1 | 0 | 2 |
| 0 | 0 | 1 | 1 | 3 |
| 0 | 1 | 0 | 0 | 4 |
| 0 | 1 | 0 | 1 | 5 |
| 0 | 1 | 1 | 0 | 6 |
| 0 | 1 | 1 | 1 | 7 |
| 1 | 0 | 0 | 0 | 8 |
| 1 | 0 | 0 | 1 | 9 |
| 1 | 0 | 1 | 0 | 10 |
| 1 | 0 | 1 | 1 | 11 |
| 1 | 1 | 0 | 0 | 12 |
| 1 | 1 | 0 | 1 | 13 |
| 1 | 1 | 1 | 0 | 14 |
| 1 | 1 | 1 | 1 | 15 |




Instruction: Battery module BMS slave dip address is set as 1 to 9 from bottom to top according to the assembly position of battery module.

5 Electrical Connection

5.1 Internal wiring of equipment

5.1.1 Connection of grounding wire and communication wire


Connect the grounding points of the base, battery module, and inverter in turn, and fasten the grounding wire with grounding screws.



5.1.2 Power line connection

Both ends of the anode connection line between battery and inverter are orange, and both ends of the cathode connection line between battery and inverter are black.

The anode end of the battery series wire is orange and the cathode end is black;



| S/N | Name | Illustration | Description |
|-----|-----------------------|---|--|
| 1 | Grounding wire |  | Grounding |
| 2 | Communication harness |  | Communication link between battery boxes Communication wire is installed from top to bottom. First, insert the plug into the socket. After pushing the metal part of the plug forward, rotate it clockwise. The connection is completed when a beep sound is heard. |

| S/N | Name | Illustration | Description |
|-----|-------------------------------------|---|--|
| 1 | Anode of power output line (Orange) |  | To connect inverter "B +" and battery "B +". |

| | | | |
|---|--|---|--|
| 2 | Cathode of power output line (Black) |  | To connect inverter "B-" and battery "B-". |
| 3 | Battery series wire (Black and orange) |  | To connect "B+" and "B -" of adjacent batteries Black end is connected with B-, and orange end with B+. |

Precautions for connector installation


The locating ring of the battery anode/cathode socket can be rotated, and there are two locating slots. Before connecting the cable, make the locating slot indicated by the socket arrow face outward (B+ is to the left, B- is to the right)

①



B+

Locating slot




①




B-

Locating slot



The power line plug has two locating pins. Align the plug with the socket arrow, insert the power line plug into the socket, and complete the connection when a crisp sound is heard.

Slot



②

③

Power-on check of battery: after the internal cables are connected, test whether the battery high voltage system can be turned on normally according to steps 2 and 3 of Chapter 6.1. If it fails to turn on, please check again whether the internal wiring of equipment is correct and whether the connector is plugged in place. After confirming that it can be started normally, please turn off the battery high voltage system according to steps 5 and 6 of Chapter 6.2, and then complete the external wiring of the equipment.

5.2 External wiring of equipment

5.2.1 Inverter grid input and load output wires (single-phase model versus three-phase model)

1. AC input (Grid connection) (single-phase models)

Hybrid inverter is specially designed for single-phase power grid. Voltage is 230V and the frequency is 50Hz/60Hz (automatic detection frequency).

Miniature breaker shall be installed between the inverter and power grid, and no load shall be directly connected to the inverter

Step 1: Check the grid voltage

- 1.1 Check whether the grid voltage/range conforms to the grid voltage range of equipment (230V/176Vac ~ 270Vac).
- 1.2 Disconnect the AC input power supply, and turn off LC-E2 (operate 5min after shutdown) to ensure that the whole equipment is powered off.

Step 2: Select the wire to connect with cold-pressed terminal.

Step 3: Fit the grid cable through the grid port and connect the grid cable to the grid terminal.

2. Load output (EPS connection) (single-phase models)

The inverter has grid-connected and off-grid functions. When the power grid is connected, the inverter enables the output through the AC port. Output is enabled through EPS port when power grid is disconnected

Miniature breaker shall be installed between the inverter and load, and no load shall be directly connected to the inverter

Step 1: Check the voltage of EPS port

- 1.1 Check whether the voltage/range of EPS port conforms to the grid voltage range of equipment (230V/176Vac ~ 270Vac)
- 1.2 Disconnect the AC input power supply, and turn off LC-E2 (operate 5min after shutdown) to ensure that the whole equipment is powered off.

Step 2: Select the wire to connect with cold-pressed terminal.

Step 3: Fit the load cable through EPS port and connect the load cable to the load terminal.

3. AC input (Grid connection) (three-phase models)

Hybrid inverter is specially designed for three-phase power grid. Voltage is 380V and the frequency is 50Hz/60Hz (automatic detection frequency).

Miniature breaker shall be installed between the inverter and power grid, and no load shall be directly connected to the inverter

Step 1: Check the grid voltage

- 1.1 Check whether the grid voltage/range conforms to the grid voltage range of equipment (380V between live wires and 230V between live wire and null wire).
- 1.2 Disconnect the AC input power supply, and turn off LC-E2 (operate 5min after shutdown) to ensure that the whole equipment is powered off.

Step 2: Select the wire to connect with cold-pressed terminal.

Step 3: Fit the grid cable through the grid port and connect the grid cable to the grid terminal.

4. Load output (BACK-UP1/BACK-UP2 connection) (three-phase models)

The inverter has grid-connected and off-grid functions. When the power grid is connected, the inverter enables the output through the AC port. Output is enabled through BACK port when power grid is disconnected

Miniature breaker shall be installed between the inverter and load, and no load shall be directly connected to the inverter

Step 1: Check the voltage of **BACK** port

- 1.1 Check whether the voltage/range of **BACK** end conforms to the grid voltage range of equipment (380V between live wires and 230V between live wire and null wire).
- 1.2 Disconnect the AC input power supply, and turn off LC-E2 (operate 5min after shutdown) to ensure that the whole equipment is powered off.

Step 2: Select the wire to connect with cold-pressed terminal.

Step 3: Fit the load cable through **BACK** port and connect the load cable to the load terminal.

5. Generator input (DG) (three-phase models)

Hybrid inverter is specially designed for three-phase power grid. Voltage is 380V and the frequency is 50Hz/60Hz (automatic detection frequency).

Miniature breaker shall be installed between the inverter and generator, and no load shall be directly connected to the inverter


Step 1: Check the output voltage of generator

- 1.1 Check whether the output voltage/range of generator conforms to the grid voltage range of equipment (380V between live wires and 230V between live wire and null wire).
- 1.2 Disconnect the AC input power supply, and turn off LC-E2 (operate 5min after shutdown) to ensure that the whole equipment is powered off.


Step 2: Select the wire to connect with cold-pressed terminal.

Step 3: Fit the grid cable through the grid (DG) port and connect the grid cable to the grid (DG) terminal.

Schematic diagram of single-phase model wiring:



Schematic diagram of three-phase model wiring:



Definitions of inverter communication ports:

| No. | Name | Description |
|-----|---------|---|
| 1 | NTC | Lead-acid battery sampling, not yet developed; |
| 2 | CAN | Internal communication (parallel), not developed yet |
| 3 | BMS | To connect with BMS communication wire of lithium battery |
| 4 | DRY IO | Dry contact, not yet developed; |
| 5 | CT | To connect the grid side CT (transformer) |
| 6 | DRM | Reserved interface to be developed |
| 7 | UP DATE | Upgrade port for USB firmware |

5.2.2 PV input wire

Instructions:

1. PV input voltage range of 9/10/11kW single-phase models is 125V-500Vdc, and the maximum open circuit voltage is 550Vdc. It is recommended that the number of PV modules in series per channel is 6-10.

2. PV input voltage range of 6/8/10/12/15kW three-phase models is 180V-850Vdc, and the maximum open circuit voltage is 1000Vdc. It is recommended that the number of PV modules in series per channel is 8-16.

The open circuit voltage (VOC) of PV module shall not be greater than the maximum open circuit voltage of inverter MPPT (e.g., maximum open circuit voltage of PV array < 550V for the single-phase models or < 1000V for three-phase models)

The open circuit voltage (VOC) of PV module shall be higher than the minimum voltage of battery.

The voltage of the maximum power PV module (V_{mp}) shall be close to or within the optimal VMP of the inverter. If one PV module cannot meet this requirement, multiple PV modules shall be connected in series. Please refer to the table below.

| Solar charging mode (MPPT) | | | | | |
|--|---|---------------------|---------------------|--------------------|--------------------|
| Inverter model | 9kW - single phase | 10kW - single phase | 11kW - single phase | | |
| Maximum input power of PV | 11.7kW | 13kW | 14.8kW | | |
| Number of MPPT controller channels | 2 channels of MPPT / number of parallel controllers of each channel - 2 in parallel | | | | |
| PV charge current | 4*12A | 4*12A | 4*12A | | |
| Maximum open circuit voltage of PV array | 550V | | | | |
| MPPT voltage range of PV array | 180V~500V | | | | |
| | | | | | |
| Inverter model | 6kW - three-phase | 8kW - three-phase | 10kW - three-phase | 12kW - three-phase | 15kW - three-phase |
| Maximum input power of PV | 9kW | 12kW | 15kW | 18kW | 22.5kW |
| Number of | 2 channels of MPPT / number of parallel controllers of each channel - 1 in | | | | |


| | | | | | |
|--|-----------|-------|-------|-------|-------|
| MPPT controller channels | parallel | | | | |
| PV charge current | 2*13A | 2*13A | 2*13A | 2*13A | 2*13A |
| Maximum open circuit voltage of PV array | 1000V | | | | |
| MPPT voltage range of PV array | 180V~850V | | | | |

Step 1: connection steps of PV panel:


1. Check PV components:
 - 1.1 Measure the voltage of module array with a multimeter
 - 1.2 Check whether the PV + and PV- connections between PV string and all-in-one machine are correct
 - 1.3 Ensure that PV module anode and cathode impedance to ground is of M Ω grade

Step 2: wiring steps of PV connector


- 1 Prepare the harness
 - 1.1 Select 12AWG conductor and cold-pressed terminal (male pin and female pin)
 - 1.2 Strip 8-10mm insulation from wire ends
 - 1.3 Insert the insulated wire into the pin contact and press it firmly with a special pressing clamp.
 - 1.4 PV cable is assembled to the back of the male or female plug after passing through the connector nut and flange head. When you feel or hear a "click" sound, the pin contact component is in place correctly
 - 1.5 Insert the PV connector into the corresponding PV connector port on the inverter



Use Staubli MC4 anode, cathode metal terminals and DC connectors. The use of other incompatible models of anode, cathode metal terminals and DC connectors may result in serious consequences, and the resulting equipment damage is not covered by the warranty.




PV string connection is as shown in the following figure




5.2.3 Distribution box wire:


1. Wiring diagram with dual power switch (optional) (single-phase models)




2. Wiring diagram without dual power switch (single-phase models):



3. Wiring diagram with dual power switch (three-phase models)



4. Wiring diagram without dual power switch (three-phase models):



5.3 Precautions for CT installation:


5.3.1 CT of single-phase model can be connected to L wire on the grid side.



All works shall be performed by trained operators with safe and appropriate tools.


This product is an open-close transformer. Please pay attention to the cleanliness of magnetic core surface when installing. If there is dirt on the magnetic core surface, the accuracy of the product will deteriorate.

1. Before the transformer is connected to the equipment, please ensure that the circuit is powered off to prevent electric shock.
2. Turn on CT as shown in Picture 1.
3. Clip the CT on the cable under test. Ensure that the maximum current in the circuit does not exceed the maximum input current of CT; the current is in the direction of the arrow on the CT shell, i.e. the arrow points to grid side.
4. Fasten the CT. At this time, the cable under test shall be inside the CT window (see Picture 2)
5. Fix the CT to the cable under test with nylon tie to prevent the CT from sliding (see Picture 3)
6. Connect the CT output black line (RJ45) to the CT communication port of inverter. (See Picture 4).
7. After checking that the circuit is correct, turn on the power supply that CT starts to measure the current in the circuit.

| Picture 1 | Picture 2 | Picture 3 | Picture 4 |
|---|---|--|---|
|  |  |  |  |
| Turn on CT | Install CT | Fix CT | Connect CT output |

5.3.2 Installation mode of the three-way camera CT


Referring to chapter 5.3.1, the CT installation method, the difference is that the A, B, and C three-phase cables are all connected to the CT, as shown in the figure below:



| Phase A(U) | Phase B(V) | Phase C(W) | RJ45 8pin |
|----------------------------|---------------------------|-------------------------|--------------------------|
| Yellow-black stranded wire | Green-black stranded wire | Red-black stranded wire | CT interface of inverter |

5.4 Definitions of COM interfaces

Inverter COM port



Definition of COM1/DB9 interface:

| Pin | Description | Network name | Type | Description |
|-----|------------------------|--------------|-------|--------------------|
| 9 | Power supply | VCC | POWER | +5Vdc power supply |
| 7 | Data communication | A | I/O | RS485_A line |
| 8 | Data communication | B | I/O | RS485_B line |
| 5 | Power supply grounding | GND | GND | GND |

5.5 Installation of WiFi data collector

5.5.1 Funtion introduction

Data collection bar (WiFi) can monitor PV power generation system for a long time by collecting and recording the working status and power generation of inverter. Collection bar can be connected with a single inverter through "RS485 interface", and receive various information of PV system from the inverter. Meanwhile, the system cloud platform can provide powerful data support for the collection bar. Collection bar sends the data to the monitoring platform wirelessly, and the real-time status and historical data of PV system can be presented in the form of charts, which is intuitive, clear and easy to understand. WiFi module is integrated inside the collection bar, so data can be transmitted through WiFi network.

5.5.2 Function introduction

Install the data collector into the COM port (DB9 interface) and tighten the flange fixing screw to complete the installation.

6 Power On/Off

6.1 Power on

Step 1: Check whether the harness is correctly connected according to the requirements of the manual (grounding wire, battery power line, communication wire, external power distribution (including CT) and PV wire). Please confirm that all of them have been connected properly and have passed the safety acceptance.

Step 2: Close the BAT Breaker on the right side of inverter cabinet;

Step 3: Turn on the DC breaker of the battery box body from top to bottom or from bottom to top;


Step 4: After confirming that the emergency stop button (STOP) is open (normally close contact is closed), press the green start button (Start) on the back panel of inverter cabinet. It is estimated that the click sound of internal relay after 2-3s will be heard, and the high-voltage system of battery pack will be started;


Step 5: Turn the PV rotary switch on the left side of inverter cabinet. If PV is not installed, PV switch may not be turned on.

At this point, the all-in-one machine is started.

The legend of operation is attached as follows:

- ① Close the breaker of inverter cabinet;
- ② Turn the DC breaker of single battery to NO from bottom to top;
- ③ Press Start button (green)





6.2 Shutdown:



If the all-in-one machine is out of service for a long time, please make sure that the power is above 50% of SOC before shutdown, and replenish the power every 3 months. Do not store the machine for a long time when the power is lower than 10% of SOC

Step 1: Disconnect the EPS from the electricity load.

Step 2: Disconnect the grid from the GRID of all-in-one machine.


Step 3: Turn the PV rotary switch to OFF position.

Step 4: Disconnect the BAT Breaker on the right side of inverter cabinet.

Step 5: Press the emergency stop button (STOP) to shut down the high-pressure box system (rotate it to the right and return it to the open status).

Step 6: Disconnect DC breaker of each battery box from top to bottom.

At this point, the all-in-one machine is shut down.



① Disconnect the battery breaker

③ Switch the DC breaker of single battery to OFF from top to bottom in sequence

7 Instructions of APP

7.1 Product Introduction

Lenercom APP is a client for PV and energy storage system monitoring and control provided for LC-E2. Customers can remotely view the operating parameters of LC-E2 through APP, monitor the running status and working conditions of equipment, and remotely issue control commands, thus realizing remote management of LC-E2.

7.2 APP download

(1) Overseas Android users visit Google Store and search for "Lenercom" to download (or download by scanning QR code on the last page of manual).




(2) IOS users visit app store and search for "Lenercom EMS" to download for installation (or download by scanning QR code on the last page of manual).



7.3 Functional description

Login



Launch the app to see the following interface. Users with existing accounts shall enter the account password to log in




- ① Enter the account number
(email or cell phone number)
- ② Enter the password
- ③ Click “Login”

Registration

After downloading the APP, the new user launches APP to enter the homepage, and clicks "Register Now" to enter the registration page. Two registration modes are provided: email registration or cell phone registration. After selecting the registration method, complete the registration steps according to the prompts (the country is a required option), and return to the login page to complete the login. (Cell phone registration only available in Chinese mainland)



Email registration



- ① Select the email registration
- ② Enter the email account
- ③ Click to get the verification code
- ④ Enter the email verification code
- ⑤, ⑥ Set the login password
- ⑦ Select your country (required)
- ⑧ Click register, and after completing the register, return to the homepage and enter the account number and password to log in.

Addition of power station

Addition of first power station

The power station addition function can add power station without ownership and consists of two addition modes (4G RTU and WiFi) according to the communication module.




① Select the power range of equipment to be added.


② Select the model of equipment to be added.

③ Enter sn code or click on the scan mark to scan the communication QR code on the back of machine


④ Click “OK” to add.




The communication module can be added by scanning the QR code or filling in the PN code which can be scanned or viewed under the inverter nameplate.




For adding a power station for the first time, APP will directly enter the prompt page of adding power station after the account is logged in, and click it to add your first power station, and complete the addition of first power station according to the prompts. See Instructions for Lenercom APP for detailed operation steps. After adding the first power station, enter the homepage as shown in the following figure. At this time, you can view the operation data of power station on APP.




Addition of multiple power stations



Step 2: Select the power station management page.





Step 1: Enter the "Personal



Step 3: Click "Add Power Station" to start adding new


Instruction: Multiple power stations can be added under the same account number, and one power station can only be added to one account number.

View the data of power station



8 Setting

8.1. Control panel




| S/N | Name | Description |
|-----|----------------------|---|
| A | LCD display | To display all information about the whole machine |
| B | Indicator | On: Inverter works in grid-connected mode Off: Inverter works not in grid-connected mode |
| C | | On: Inverter works in off-grid mode Off: Inverter works not in off-grid mode |
| D | | On: Warning for whole machine Off: No warning for whole machine |
| E | | On: Serious fault of whole machine Off: No fault of whole machine |
| F | Touch screen buttons | Esc: Return from the current setting interface |
| G | | Up: Move the cursor up or increase the setting value |
| H | | Down: Move the cursor down or decrease the setting value |
| I | | Enter: Confirm and save the current settings |

8.2 Description of LED indicator


| Status of whole machine | Grid (Green) | EPS (Green) | Alarm (yellow) | Fault (red) |
|-------------------------|--------------|-------------|----------------|-------------|
| Initialization | Off | Off | Off | Off |
| Standby | Off | Off | Off | Off |
| Grid-connected | On | Off | Off | Off |
| Off-grid | Off | On | Off | Off |
| Bypass | Off | On | On | Off |
| Fault | Off | Off | Off | On |

8.3 Quick setup guide

Summary of display items




8.4 Operation method of setting item



- ① Cycle interface, touch the ESC button lightly
- ② Press Enter button and click Equipment
- ③ Set the password
- ④ Enter password: 00000
- ⑤ Click Enter to the next step
- ⑥ Enter the password: 00000, and click Enter
- ⑦ Enter the setting menu

Examples:


Peak load shifting



8.5 Detailed description of display and setting parameters


8.5.1 Description of parameter information

Display parameters of PV




Caution: Single-phase high-voltage equipment has 4 channels of display; 3-phase high-voltage equipment has 2 channels of display.

DC voltage display




Battery parameters




Caution: the real-time rated voltage of high-voltage device of battery is 51.2 V*N; N is the number of battery boxes.

Battery information




Caution: Battery type: lithium battery by default


BMS parameters




Parameters of grid side




Inverter parameters




Load parameters



Inverter power and grid power



PV, load, battery power



Temperature

| LCD interface | | | | | | | | | |
|--|-------------|--|-----------|------|-------|------|--------------|------|---|
| <table border="1"> <thead> <tr> <th colspan="2">Temperature</th> </tr> </thead> <tbody> <tr> <td>Inverter:</td> <td>25°C</td> </tr> <tr> <td>DCDC:</td> <td>26°C</td> </tr> <tr> <td>Environment:</td> <td>27°C</td> </tr> </tbody> </table> | Temperature | | Inverter: | 25°C | DCDC: | 26°C | Environment: | 27°C | <p>→ Real-time temperature of radiator on the inverter side</p> <p>→ Real-time temperature of radiator on the DCDC side</p> <p>→ Ambient temperature inside the whole machine</p> |
| Temperature | | | | | | | | | |
| Inverter: | 25°C | | | | | | | | |
| DCDC: | 26°C | | | | | | | | |
| Environment: | 27°C | | | | | | | | |

Status information

| LCD interface | Detailed information | | | | | | |
|---|----------------------|--|---------|----------------------|-----------|---------|---|
| <table border="1"> <thead> <tr> <th colspan="2">Status information</th> </tr> </thead> <tbody> <tr> <td>System:</td> <td>Power supply of grid</td> </tr> <tr> <td>Inverter:</td> <td>Standby</td> </tr> </tbody> </table> | Status information | | System: | Power supply of grid | Inverter: | Standby | <p>System: the status information of whole machine, including initialization, standby PV grid connection, battery grid connection, hybrid power supply, grid charging, PV charging, grid power supply, fault mode, etc</p> <p>Inverter: the status information of inverter, including standby, off-grid, grid-connected, off-grid tracking, etc</p> <p>DCDC: the status information of charge and discharge, including standby, charge mode, discharge mode, etc</p> |
| Status information | | | | | | | |
| System: | Power supply of grid | | | | | | |
| Inverter: | Standby | | | | | | |

Error information

| LCD interface | | | | | |
|---|-----------------------|--|----|-----------------------|--|
| <table border="1"> <thead> <tr> <th colspan="2">Error information</th> </tr> </thead> <tbody> <tr> <td>02</td> <td>Battery not connected</td> </tr> </tbody> </table> | Error information | | 02 | Battery not connected | <p>Where the number represents the error code and the text is the error message</p> <p>Caution: You can't turn the page when there is a lock sign in the upper right corner of the screen. You need to press Enter to unlock it first.</p> |
| Error information | | | | | |
| 02 | Battery not connected | | | | |

Caution: In case of off-grid, it is normal to indicate that the grid voltage and frequency are both low.

8.5.2 System setup

| LCD interface | Detailed information |
|---|---|
| <pre> System settings Status: Self-generating and self-use Grid connection 220/50 standard: PV input: Independence </pre> | <p>Status: the setting value of whole machine working mode, including the self-generating and self-use, peak load shifting, battery preferred</p> <p>Grid connection standard: the displayed value is the actual grid standard.</p> <p>PV input: the display value is the setting value of PV input type, including the parallel, stand-alone and constant voltage.</p> |

User settings

| LCD interface | Description |
|--|--|
| <pre> --User-- →1: Setting 2: Query 3: Statistics </pre> | <p>Press "Esc" to enter user settings;</p> |

Type in the password when entering the settings. The details are as follows:

| LCD interface | Description |
|---|---|
| <pre> -- password-- Input: XXXXXX </pre> | <p>Type in the password when entering the settings, and the default password is " _ 00000".</p> <p>Press Up/Down to adjust the password, press Enter to move the cursor forward, and press Esc to move the cursor backward;</p> |

8.5.3 Description of setting item:

| LCD interface | Detailed information |
|--|--|
| <pre> --Settings-- → 1: System settings 2: Battery parameter 3: Grid standard 4: Operation parameters </pre> | <p>This page shows the setting options, and press Up/Down to select it accordingly. Press Enter to enter the selected menu.</p> <p>There are 13 options, including system settings, battery parameters, grid standards, operation parameters, 485 address, 485 baud rate, display language, LCD backlight, date/time, clear records, set password, maintenance and factory settings.</p> |

| | |
|--|--|
| 5: 485 Address 6: 485 baud rate 7: Display Language 8: LCD Backlight 9: Date / time 10: Clear records 11: Set password 12: Maintenance 13: Factory settings | |
|--|--|

| LCD interface | Detailed information |
|---|--|
| --System settings-- → 1: Working mode 2: Backup enable 3: Battery wake-up 4: Program control enable 5: Startup latency 6: PV input type 7: Countercurrent prevention | This page shows the system setting parameters. Press Up/Down to select it accordingly. Press Enter to enter the selected menu. |

Working mode

| LCD interface | Description |
|--|--|
| --Working mode-- → 1: Self-generating and self-use 2: Peak load shifting 3: Battery preferred | This interface is used to select the working mode. Press Esc to return to the setting interface. |

When peak load shifting is selected, the charge and discharge time shall be set accordingly. (A total of 3 periods can be set)

| LCD interface | Description |
|--------------------------|---|
| Start of charge: 00:00 | This interface is used to select the offset time of peak load. Press Up/Down to move to the appropriate option. Press Enter to enter the selected menu. Press Esc to return to the interface of working mode. |
| End of charge: 00:00 | |
| Start of discharge 00:00 | |
| End of discharge: 00:00 | |

Backup enable

| LCD interface | Description |
|---|--|
| -- Backup enable-- → 1. Disabled 2. Enabled | When the grid and PV are turned off, the battery is enabled to supply power to the load. Default option is “Enabled”. |

Battery wake-up

| LCD interface | Description |
|---|---|
| -- Battery wake-up-- → 1. Disabled 2. Enabled | Enable settings of battery wake-up Default option is “Disabled”. |

Program control enable

| LCD interface | Description |
|--|--|
| -- Program control enable-- → 1. Disabled 2. Enabled | When you want to control the machine remotely, you need to enable it. Default option is “Disabled”. |

Startup latency

| LCD interface | Description |
|---|---|
| --Startup latency-- Input: 60 Unit: S | Input value ranges from 20 to 300, depending on the criteria. |

Caution: Default duration is 60S.

PV input type

| LCD interface | Description |
|---|---|
| --Input mode-- → 1: Independence 2: Parallel 3: Constant voltage | PV input mode setting Default factory option is “stand-alone”; When the parallel input is set to stand-alone mode, PV power will be unbalanced. |

8.5.4 Battery parameter


| LCD interface | Description |
|--|--|
| --Battery parameters-- 1: Battery type 2: Discharge depth of battery 3: Charge current of battery | This interface is used to select the battery parameters. Press Up/Down to move to the appropriate option; Press Enter to enter the selected menu; Press Esc to return to the setting interface; |

Battery type: lithium battery by default, and the setting cannot be changed.

Discharge depth of battery

| LCD interface | Description |
|--|--|
|  | DOD1: Grid-connected discharge depth. DOD2: Off-grid discharge depth. Default factory settings of DOD1, DOD2 and backlash are respectively 90%, 90% and 10%. |

Charge current of battery

| LCD interface | Description |
|---|---|
|  | Charge current is settable Factory default value is 25A. |

Operation parameters

| LCD interface | Description |
|--|---|
| -- Operation parameters-- → 1: Reactive mode 2: Grid-connected power 3: Discharge power 4: Low grid voltage 5: High grid voltage 6: Low grid frequency 7: High grid | Press Up/Down to move to the appropriate option; Press Enter to enter the selected menu; Press Esc to return to the setting interface. Options include reactive power mode, grid-connected power, discharge power, low grid voltage, high grid voltage, low grid frequency and high and low grid frequency/high grid frequency (see ① to ⑦) |

| | |
|-----------|--|
| frequency | |
|-----------|--|

Reactive mode

| LCD interface | Description |
|---|---|
| -- Reactive mode-- → 1: Power factor control 2: Reactive control 3: QU curve | Press Up/Down to move to the appropriate option; Press Enter to enter the power factor setting interface; (Select 2, press Enter to confirm the input and enter the reactive power interface; select 3, 4 to select the corresponding mode and return to the parameter setting interface); press Esc to cancel the input and return to the operation parameter interface. |

Caution: The default is power factor control.

Grid-connected power:

| LCD interface | Description |
|---|---|
| -- Grid-connected power-- Input: 100% <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> Value range (0~100) </div> | Press Up/Down to adjust the input number; Press Enter to confirm, or press Esc to cancel the input and return to the operation parameter interface; The input value shall be between 0 and 100. |

Caution: The default is 100%.

Discharge power

| LCD interface | Description |
|--|---|
| -- Discharge power-- Input: 050% <div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 10px auto;"> Value range (0~100) </div> | Press Up/Down to adjust the input number; Press Enter to confirm, or press Esc to cancel the input and return to the operation parameter interface; The input value shall be between 0 and 100. |

Caution: The default is 100%

Low voltage protection of grid

| LCD interface | Description |
|--|--|
| --Low voltage of grid-- Input: Unit: V Value range (176~270 V) | Low voltage protection point of grid. Press Up/Down to adjust the input number; Press Enter to confirm the input; Press Esc to cancel the input and return to the operation parameter interface; The value shall be between 176 V and 270 V, which varies with different standards |

High voltage protection of grid

| LCD interface | Description |
|--|--|
| -- High voltage of grid-- Input: Unit: V Value range (240~280 V) | Overvoltage protection point of grid Press Up/Down to adjust the input value; Press Enter to confirm the input; Press Esc to cancel the input and return to the operation parameter interface; The value shall be between 240 V and 280 V, which varies with different standards |

Low frequency of grid

| LCD interface | Description |
|--|---|
| -- Low frequency of grid -- Input: Unit: Hz Value range (45~49.8) | Low frequency protection point of grid Press Up/Down to adjust the input value; Press Enter to confirm the input; Press Esc to cancel the input and return to the operation parameter interface; The value is between 45 and 49.8, which varies with different standards. |

High frequency of grid

| LCD interface | Description |
|--|--|
| -- High frequency of grid -- Input: 52.0 Unit: Hz Value range (50.5~55) | Overclocking protection point of grid Press Up/Down to adjust the input value; Press Enter to confirm the input; Press Esc to cancel the input and return to the operation parameter interface; The value is between 50.5 and 55, which varies with different standards. |

485 Address

| LCD interface | Description |
|--|---|
| -- 485 Address-- Input: 1 <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-left: 20px;"> Value range (1~64) </div> | Press Up/Down to adjust the input value; Press Enter to confirm, or press Esc to cancel the input and return to setting interface; The input value shall be between 1 and 64. |

Caution: The default is 1, which can not be changed

485 baud rate

| LCD interface | Description |
|--|---|
| --Select-- 1: 2400 bps 2: 4800 bps →3: 9600 bps | Press Up/Down to move to the appropriate option; Press Enter to confirm, or press Esc to cancel the input and return to setting interface; There are three options available: 2400/4800/9600. |

Language:

| LCD interface | Description |
|--|---|
| -- Display Language-- →1: Chinese 2: ENGLISH | Press Up/Down to move to the appropriate option; Press Enter to confirm, or press Esc to cancel the input and return to setting interface; |

Caution: The default language is Chinese in China (including Hong Kong and Taiwan) and English in other areas.

LCD backlight

| LCD interface | Description |
|---|---|
| --Backlight time-- Input: 20 Unit: s Value range (20~120) | Press Up/Down to adjust the input value; Press Enter to confirm, or press Esc to cancel the input and return to setting interface; The input value shall be between 20 and 120. |

Date / time

| LCD interface | Description |
|---|---|
| -- Date / time-- Date: 9/19/2018 Time: 10: 01: 12 Saturday | Press Up/Down to adjust the input value; Press Enter to confirm the input and return to setting interface; Press Enter to return to the setting interface; The input value shall be between 2000 and 2099. |

Caution: When the equipment is turned on for the first time, the user shall set the time and date for calibration.

Clear records

| LCD interface | Description |
|--|---|
| -- Clear records-- →1: Cancel 2: Enter | Clear all previous history records in the Query/Record menu. Press Up/Down to move to the appropriate option; Press Enter to confirm, or press Esc to cancel the selection and return to setting interface; |

Password setting

| LCD interface | Description |
|---|--|
| <p>-- Password-- Old: XXXXX New: XXXXX Enter: XXXXX</p> | <p>This interface will be used to change the password entering the setting interface; Press Up/Down to adjust the input value; Press Enter to move the cursor backward, confirm the modification and return to the setting interface Press Esc to move the cursor forward and return to the setting interface;</p> |

Maintenance

| LCD interface | Description |
|--------------------------|------------------------------------|
| <p>→ 12: Maintenance</p> | <p>Maintenance personnel only.</p> |

Factory settings

| LCD interface | Description |
|--|---|
| <p>-- Factory settings-- →1: Cancel 2: Enter</p> | <p>Press Up/Down to move to the appropriate option; Press Enter to confirm the selection;</p> |

8.5.5 Query

| LCD interface | Description |
|--|--|
| <p>--Query-- → 1: Model 2: SN 3: Software version 4: Operation records</p> | <p>Press Up/Down to move to the appropriate option; Press Enter to confirm the selection; Press Esc to return to User interface (see 8.1.16); There are four options: model, SN, software version, and operation record (see 1 through 4).</p> |

Model

| LCD interface | Description |
|------------------|---|
| <p>--Model--</p> | <p>This interface displays the model of the inverter. Press Esc to return to the query interface.</p> |

SN

| LCD interface | Description |
|--|--|
| --SN-- GUID: 05DBFF38 430987323639424E | This interface displays SN of the inverter. This is unique for any equipment or in any context. |

Software version

| LCD interface | Description |
|---|--|
| -- Software version-- ARM: V1.00.21 DSP: V1.01.10 | The interface displays software versions of inverter ARM and DSP; Press Esc to return to the query interface. |

Operation records

| LCD interface | Description |
|--|--|
| --Record (01)-- 02: BATTERY NOT CONNECTED APPEAR: AUGUST 12, 15:12 DISAPPEAR: | Record (01): Total number of fault records (up to 500) (those marked as 1 are the latest fault or alarm); 02: fault code Appear: the time when the fault occurs; Press Up/Down to view the record; press Enter to enter the description interface of corresponding record; press Esc to return to the query interface. |

8.5.6 Statistics

| LCD interface | Description |
|---|--|
| <p>--Statistics--</p> <p>→ 1: Time statistics</p> <p>2: Number of grid connections</p> <p>3: Peak power</p> <p>4: Power generation of the day</p> <p>5: Power generation of the month</p> <p>6: Power generation of the year</p> <p>7: Total power generation</p> | <p>This interface is used to select statistical items;</p> <p>Press Up/Down to move to the appropriate option;</p> <p>Press Enter to enter the selected menu;</p> <p>Press Esc to return to the user interface;</p> <p>There are seven options in total:</p> <p>Time statistics/number of grid connection/peak power/power generation of the day/power generation of the month/power generation of the year/total power generation (see 1 to 7).</p> |

Time statistics

| LCD interface | Description |
|--|---|
| <p>--Time--</p> <p>Operation 5</p> <p>Grid-connected 0</p> <p>Unit hours</p> | <p>Operation time of inverter (hours)</p> <p>Grid connection time (hours)</p> <p>Press Esc to return to the Statistics interface.</p> |

Number of grid connections

| LCD interface | Description |
|---|---|
| <p>-- Number of grid connections--</p> <p>Value 5</p> | <p>This interface displays the number of grid connections for inverter.</p> <p>Press Esc to return to the Statistics interface.</p> |

Peak power

| LCD interface | Description |
|---|--|
| <p>-- Peak power--</p> <p>After start: 5000</p> <p>Peak value 0</p> <p>of the day:</p> <p>Unit: W</p> | <p>This interface displays historical records and peak power of the day.</p> <p>Press Esc to return to the Statistics interface.</p> |

Power generation of the day

| LCD interface | Description |
|--|---|
| <p>--Current day-- PV: 0.0 KWH Grid-connected: 0.0 KWH Energy 0.0 KWH consumption:</p> | <p>This interface displays the power generation of the day (kWh) PV power generation; Grid-connected power generation; Power consumption of load and inverter; Press Esc to return to the Statistics interface.</p> |

Power generation of the month

| LCD interface | Description |
|--|---|
| <p>--Current month-- PV: 0.0 KWH Grid-connected: 0.0 KWH Energy 0.0 KWH consumption:</p> | <p>This interface displays the power generation of the month (kWh) PV power generation; Grid-connected power generation; Power consumption of load and inverter; Press Esc to return to the Statistics interface.</p> |

Power generation of the year

| LCD interface | Description |
|---|--|
| <p>--Current year-- PV: 0.0 KWH Grid-connected: 0.0 KWH Energy 0.0 KWH consumption:</p> | <p>This interface displays the power generation of the year (kWh) PV power generation; Grid-connected power generation; Power consumption of load and inverter; Press Esc to return to the Statistics interface.</p> |

Total power generation

| LCD interface | Description |
|--|--|
| <p>-- Total power generation-- PV: 0.0 KWH Grid-connected: 0.0 KWH Energy 0.0 KWH consumption:</p> | <p>This interface displays the total power generation (kWh) PV power generation; Grid-connected power generation; Power consumption of load and inverter; Press Esc to return to the Statistics interface.</p> |

9 Technical Data

9.1 Parameter list of single-phase model

| Model | | LC-E2-915S | LC-E2-920S | LC-E2-925S | LC-E2-930S |
|-----------------------------|--|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Voltage of battery | | 153.6V | 204.8V | 256V | 307.2V |
| PV parameters | Maximum input power of PV | 11.7kW | 11.7kW | 11.7kW | 11.7kW |
| | Maximum DC voltage | 550V | 550V | 550V | 550V |
| | MPPT voltage range/ rated voltage | 125V~500V/360V | 125V~500V/360V | 125V~500V/360V | 125V~500V/360V |
| | Maximum input current of each pack | 12A | 12A | 12A | 12A |
| | Number of MPPT / Maximum number of strings in parallel of each pack | 2/2 | 2/2 | 2/2 | 2/2 |
| Battery data | Battery voltage range | 125~175V | 166~233V | 208~292V | 249~350V |
| | Rated voltage of battery pack | 153.6V | 204.8V | 256V | 307.2V |
| | Battery capacity | 5.12kWh*3 | 5.12kWh*4 | 5.12kWh*5 | 5.12kWh*6 |
| | Maximum charge/ discharge current | 80A/80A | 80A/80A | 80A/80A | 80A/80A |
| | Battery type | Lithium iron phosphate battery |
| | Communication interface | CAN | CAN | CAN | CAN |
| Grid-connected output/input | Rated output power | 9kW | 9kW | 9kW | 9kW |
| | Rated output current | 39.2A | 39.2A | 39.2A | 39.2A |
| | Grid voltage / range | 230V/176Vac~270Vac | 230V/176Vac~270Vac | 230V/176Vac~270Vac | 230V/176Vac~270Vac |
| | Frequency of grid | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Power factor | 0.99 lead-0.99 lag (settable) |
| | THDI | <2% | <2% | <2% | <2% |
| | Grid connection type | L+N+PE | L+N+PE | L+N+PE | L+N+PE |
| Off-grid output | Rated output power | 9kW | 9kW | 9kW | 9kW |
| | Overload protection | 125%, 60S/150%,1S | 125%, 60S/150%,1S | 125%, 60S/150%,1S | 125%, 60S/150%,1S, 1S |
| | Rated output voltage | 230Vac | 230Vac | 230Vac | 230Vac |
| | Rated output current | 39.2A | 39.2A | 39.2A | 39.2A |
| | Rated output | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|----------------------|--|---|---|---|---|
| | frequency | | | | |
| | Automatic switching duration | <20ms | <20ms | <20ms | <20ms |
| | THDU | <2% | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 96% | 96% | 96% | 96% |
| | Maximum efficiency | 98.2% | 98.2% | 98.2% | 98.2% |
| | European efficiency | 97.2% | 97.2% | 97.2% | 97.2% |
| | MPPT efficiency | 99% | 99% | 99% | 99% |
| General data | Dimensions (W/D/H) | 600mm/420mm/1550mm | 600mm/420mm/1750mm | 600mm/420mm/1950mm | 600mm/420mm/2150mm |
| | Net weight | 245Kg | 299Kg | 353Kg | 407Kg |
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C ~55°C | -15°C ~55°C | -15°C ~55°C | -15°C ~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional |

| Model | | LC-E2-1015S | LC-E2-1020S | LC-E2-1025S | LC-E2-1030S |
|--------------------|--|--------------------------------|--------------------------------|--------------------------------|--------------------------------|
| Voltage of battery | | 153.6V | 204.8V | 256V | 307.2V |
| PV parameters | Maximum input power of PV | 13kW | 13kW | 13kW | 13kW |
| | Maximum DC voltage | 550V | 550V | 550V | 550V |
| | MPPT voltage range/ rated voltage | 125V~500V/360V | 125V~500V/360V | 125V~500V/360V | 125V~500V/360V |
| | Maximum input current of each pack | 12A | 12A | 12A | 12A |
| | Number of MPPT / Maximum number of strings in parallel of each pack | 2/2 | 2/2 | 2/2 | 2/2 |
| Battery data | Battery voltage range | 125~175V | 166~233V | 208~292V | 249~350V |
| | Rated voltage of battery pack | 153.6V | 204.8V | 256V | 307.2V |
| | Battery capacity | 5.12kWh*3 | 5.12kWh*4 | 5.12kWh*5 | 5.12kWh*6 |
| | Maximum charge/ discharge current | 80A/80A | 80A/80A | 80A/80A | 80A/80A |
| | Battery type | Lithium iron phosphate battery |
| | Communication interface | CAN | CAN | CAN | CAN |
| Rated output power | 10kW | 10kW | 10kW | 10kW | |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|----------------------|--|---|---|---|---|
| | Rated output current | 43.5A | 43.5A | 43.5A | 43.5A |
| | Grid voltage / range | 230V/176Vac~270Vac | 230V/176Vac~270Vac | 230V/176Vac~270Vac | 230V/176Vac~270Vac |
| | Frequency of grid | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Power factor | 0.99 lead-0.99 lag (settable) |
| | THDI | <2% | <2% | <2% | <2% |
| | Grid connection type | L+N+PE | L+N+PE | L+N+PE | L+N+PE |
| Off-grid output | Rated output power | 10kW | 10kW | 10kW | 10kW |
| | Overload protection | 125%, 60S/150%,1S | 125%, 60S/150%,1S | 125%, 60S/150%,1S | 125%, 60S/150%,1S, 1S |
| | Rated output voltage | 230Vac | 230Vac | 230Vac | 230Vac |
| | Rated output current | 43.5A | 43.5A | 43.5A | 43.5A |
| | Rated output frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Automatic switching duration | <20ms | <20ms | <20ms | <20ms |
| | THDU | <2% | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 96% | 96% | 96% | 96% |
| | Maximum efficiency | 98.2% | 98.2% | 98.2% | 98.2% |
| | European efficiency | 97.2% | 97.2% | 97.2% | 97.2% |
| | MPPT efficiency | 99% | 99% | 99% | 99% |
| General data | Dimensions (W/D/H) | 600mm/420mm/1550mm | 600mm/420mm/1750mm | 600mm/420mm/1950mm | 600mm/420mm/2150mm |
| | Net weight | 245Kg | 299Kg | 353Kg | 407Kg |
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C ~55°C | -15°C ~55°C | -15°C ~55°C | -15°C ~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional |

| Model | | LC-E2-1115S | LC-E2-1120S | LC-E2-1125S | LC-E2-1130S |
|-----------------------|--|----------------|----------------|----------------|----------------|
| Voltage of battery | | 153.6V | 204.8V | 256V | 307.2V |
| PV parameters | Maximum input power of PV | 14.8kW | 14.8kW | 14.8kW | 14.8kW |
| | Maximum DC voltage | 550V | 550V | 550V | 550V |
| | MPPT voltage range/ rated voltage | 125V~500V/360V | 125V~500V/360V | 125V~500V/360V | 125V~500V/360V |
| | Maximum input current of each pack | 12A | 12A | 12A | 12A |
| | Number of MPPT / Maximum number of strings in parallel of each pack | 2/2 | 2/2 | 2/2 | 2/2 |
| Battery voltage range | 125~175V | 166~233V | 208~292V | 249~350V | |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|-----------------------------|--|---|---|---|---|
| | Rated voltage of battery pack | 153.6V | 204.8V | 256V | 307.2V |
| | Battery capacity | 5.12kWh*3 | 5.12kWh*4 | 5.12kWh*5 | 5.12kWh*6 |
| | Maximum charge/discharge current | 80A/80A | 80A/80A | 80A/80A | 80A/80A |
| | Battery type | Lithium iron phosphate battery |
| | Communication interface | CAN | CAN | CAN | CAN |
| Grid-connected output/input | Rated output power | 11kW | 11kW | 11kW | 11kW |
| | Rated output current | 49.5A | 49.5A | 49.5A | 49.5A |
| | Grid voltage / range | 230V/176Vac~270Vac | 230V/176Vac~270Vac | 230V/176Vac~270Vac | 230V/176Vac~270Vac |
| | Frequency of grid | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Power factor | 0.99 lead-0.99 lag (settable) |
| | THDI | <2% | <2% | <2% | <2% |
| | Grid connection type | L+N+PE | L+N+PE | L+N+PE | L+N+PE |
| Off-grid output | Rated output power | 11kW | 11kW | 11kW | 11kW |
| | Overload protection | 125%, 60S/150%,1S | 125%, 60S/150%,1S | 125%, 60S/150%,1S | 125%, 60S/150%,1S, 1S |
| | Rated output voltage | 230Vac | 230Vac | 230Vac | 230Vac |
| | Rated output current | 49.5A | 49.5A | 49.5A | 49.5A |
| | Rated output frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Automatic switching duration | <20ms | <20ms | <20ms | <20ms |
| | THDU | <2% | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 96% | 96% | 96% | 96% |
| | Maximum efficiency | 98.2% | 98.2% | 98.2% | 98.2% |
| | European efficiency | 97.2% | 97.2% | 97.2% | 97.2% |
| | MPPT efficiency | 99% | 99% | 99% | 99% |
| General data | Dimensions (W/D/H) | 600mm/420mm/1550mm | 600mm/420mm/1750mm | 600mm/420mm/1950mm | 600mm/420mm/2150mm |
| | Net weight | 245Kg | 299Kg | 353Kg | 407Kg |
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C ~55°C | -15°C ~55°C | -15°C ~55°C | -15°C ~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional | RS485/CAN/DRM available 4G/WIFI optional |

9.2 Parameter list of three-phase model

| Model | | LC-E2-615T | LC-E2-620T | LC-E2-625T | LC-E2-630T |
|-----------------------------|---|--------------------|--------------------|--------------------|--------------------|
| PV input | Maximum PV input power | 9kW | 9kW | 9kW | 9kW |
| | Maximum PV input voltage | 1000V | 1000V | 1000V | 1000V |
| | MPPT voltage range | 180~850V | 180~850V | 180~850V | 180~850V |
| | MPPT voltage range at full power | 250~850V | 250~850V | 250~850V | 250~850V |
| | Maximum PV input current | 2*13A | 2*13A | 2*13A | 2*13A |
| | PV short circuit current | 2*16A | 2*16A | 2*16A | 2*16A |
| | Number of MPPT / Maximum number of strings in parallel of each MPPT | 2/1 | 2/1 | 2/1 | 2/1 |
| Battery parameters | Input voltage range of battery | 125~175V | 166~233V | 208~292V | 249~350V |
| | Rated voltage of battery pack | 153.6V | 204.8V | 256V | 307.2V |
| | Battery capacity | 5.12kWh*3 | 5.12kWh*4 | 5.12kWh*5 | 5.12kWh*6 |
| | Maximum charge/ discharge current | 50A/50A | 50A/50A | 50A/50A | 50A/50A |
| | Maximum charge / discharge power | 6kW | 6kW | 6kW | 6kW |
| | Battery type | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) |
| | Communication interface | CAN | CAN | CAN | CAN |
| Grid-connected output/input | Rated grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Rated output power | 6kW | 6kW | 6kW | 6kW |
| | Maximum grid-connected output apparent power | 6.6kVA | 6.6kVA | 6.6kVA | 6.6kVA |
| | Maximum grid-connected output current | 9.5A | 9.5A | 9.5A | 9.5A |
| | Maximum grid-connected input apparent power | 13.2kVA | 13.2kVA | 13.2kVA | 13.2kVA |
| | Maximum grid-connected input current | 19A | 19A | 19A | 19A |
| | Power factor | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap |
| | Total harmonic distortion rate of current | <3% | <3% | <3% | <3% |
| Off-grid output | Rated off-grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated off-grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Maximum off-grid output apparent power | 6.6kVA | 6.6kVA | 6.6kVA | 6.6kVA |
| | Maximum off-grid output current | 9.5A | 9.5A | 9.5A | 9.5A |
| | Switching duration | <20ms | <20ms | <20ms | <20ms |
| | Total harmonic distortion rate of voltage | <2% | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 97.5% | 97.5% | 97.5% | 97.5% |
| | Maximum efficiency | 97.9% | 97.9% | 97.9% | 97.9% |
| | European efficiency | 97.2% | 97.2% | 97.2% | 97.2% |
| | MPPT efficiency | 99.5% | 99.5% | 99.5% | 99.5% |
| General data | Dimensions (W/D/H) | 600mm/420mm/1550mm | 600mm/420mm/1750mm | 600mm/420mm/1950mm | 600mm/420mm/2150mm |
| | Net weight | 245Kg | 299Kg | 353Kg | 407Kg |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|--|---------------------|---|---|---|---|
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C~55°C | -15°C~55°C | -15°C~55°C | -15°C~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional |

| Model | | LC-E2-815T | LC-E2-820T | LC-E2-825T | LC-E2-830T |
|-----------------------------|---|------------------|------------------|------------------|------------------|
| PV input | Maximum PV input power | 12kW | 12kW | 12kW | 12kW |
| | Maximum PV input voltage | 1000V | 1000V | 1000V | 1000V |
| | MPPT voltage range | 180~850V | 180~850V | 180~850V | 180~850V |
| | MPPT voltage range at full power | 330~850V | 330~850V | 330~850V | 330~850V |
| | Maximum PV input current | 2*13A | 2*13A | 2*13A | 2*13A |
| | PV short circuit current | 2*16A | 2*16A | 2*16A | 2*16A |
| | Number of MPPT / Maximum number of strings in parallel of each MPPT | 2/1 | 2/1 | 2/1 | 2/1 |
| Battery parameters | Input voltage range of battery | 125~175V | 166~233V | 208~292V | 249~350V |
| | Rated voltage of battery pack | 153.6V | 204.8V | 256V | 307.2V |
| | Battery capacity | 5.12kWh*3 | 5.12kWh*4 | 5.12kWh*5 | 5.12kWh*6 |
| | Maximum charge/ discharge current | 50A/50A | 50A/50A | 50A/50A | 50A/50A |
| | Maximum charge / discharge power | 7.68kW | 8kW | 8kW | 8kW |
| | Battery type | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) |
| | Communication interface | CAN | CAN | CAN | CAN |
| Grid-connected output/input | Rated grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Rated output power | 8kW | 8kW | 8kW | 8kW |
| | Maximum grid-connected output apparent power | 8.8kVA | 8.8kVA | 8.8kVA | 8.8kVA |
| | Maximum grid-connected output current | 12.7A | 12.7A | 12.7A | 12.7A |
| | Maximum grid-connected input apparent power | 17.6kVA | 17.6kVA | 17.6kVA | 17.6kVA |
| | Maximum grid-connected input current | 25.5A | 25.5A | 25.5A | 25.5A |
| | Power factor | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap |
| | Total harmonic distortion rate of current | <3% | <3% | <3% | <3% |
| Off-grid output | Rated off-grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated off-grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Maximum off-grid output apparent power | 8.8kVA | 8.8kVA | 8.8kVA | 8.8kVA |
| | Maximum off-grid output current | 12.7A | 12.7A | 12.7A | 12.7A |
| | Switching duration | <20ms | <20ms | <20ms | <20ms |
| | Total harmonic distortion rate of voltage | <2% | <2% | <2% | <2% |
| γ | Charge/discharge efficiency of battery | 97.5% | 97.5% | 97.5% | 97.5% |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|--------------|---------------------|---|---|---|---|
| | Maximum efficiency | 97.9% | 97.9% | 97.9% | 97.9% |
| | European efficiency | 97.2% | 97.2% | 97.2% | 97.2% |
| | MPPT efficiency | 99.5% | 99.5% | 99.5% | 99.5% |
| General data | Dimensions (W/D/H) | 600mm/420mm/1550 mm | 600mm/420mm/1750 mm | 600mm/420mm/1950 mm | 600mm/420mm/2150 mm |
| | Net weight | 245Kg | 299Kg | 353Kg | 407Kg |
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C~55°C | -15°C~55°C | -15°C~55°C | -15°C~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional |

| Model | | LC-E2-835T | LC-E2-1020T | LC-E2-1025T | LC-E2-1030T |
|-----------------------------|---|------------------|------------------|------------------|------------------|
| PV input | Maximum PV input power | 12kW | 15kW | 15kW | 15kW |
| | Maximum PV input voltage | 1000V | 1000V | 1000V | 1000V |
| | MPPT voltage range | 180~850V | 180~850V | 180~850V | 180~850V |
| | MPPT voltage range at full power | 330~850V | 430~850V | 430~850V | 430~850V |
| | Maximum PV input current | 2*13A | 2*13A | 2*13A | 2*13A |
| | PV short circuit current | 2*16A | 2*16A | 2*16A | 2*16A |
| | Number of MPPT / Maximum number of strings in parallel of each MPPT | 2/1 | 2/1 | 2/1 | 2/1 |
| Battery parameters | Input voltage range of battery | 291~409V | 166~233V | 208~292V | 249~350V |
| | Rated voltage of battery pack | 358.4V | 204.8V | 256V | 307.2V |
| | Battery capacity | 5.12kWh*7 | 5.12kWh*4 | 5.12kWh*5 | 5.12kWh*6 |
| | Maximum charge/ discharge current | 50A/50A | 50A/50A | 50A/50A | 50A/50A |
| | Maximum charge / discharge power | 8kW | 10kW | 10kW | 10kW |
| | Battery type | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) |
| | Communication interface | CAN | CAN | CAN | CAN |
| Grid-connected output/input | Rated grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Rated output power | 8kW | 10kW | 10kW | 10kW |
| | Maximum grid-connected output apparent power | 8.8kVA | 11kVA | 11kVA | 11kVA |
| | Maximum grid-connected output current | 12.7A | 15.9A | 15.9A | 15.9A |
| | Maximum grid-connected input apparent power | 17.6kVA | 22kVA | 22kVA | 22kVA |
| | Maximum grid-connected input current | 25.5A | 31.9A | 31.9A | 31.9A |
| | Power factor | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap |
| | Total harmonic distortion rate of current | <3% | <3% | <3% | <3% |
| Rated off-grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|----------------------|---|---|---|---|---|
| | Rated off-grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Maximum off-grid output apparent power | 8.8kVA | 11kVA | 11kVA | 11kVA |
| | Maximum off-grid output current | 12.7A | 15.9A | 15.9A | 15.9A |
| | Switching duration | <20ms | <20ms | <20ms | <20ms |
| | Total harmonic distortion rate of voltage | <2% | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 97.5% | 97.5% | 97.5% | 97.5% |
| | Maximum efficiency | 97.9% | 98.2% | 97.9% | 97.9% |
| | European efficiency | 97.2% | 97.5% | 97.2% | 97.2% |
| | MPPT efficiency | 99.5% | 99.5% | 99.5% | 99.5% |
| General data | Dimensions (W/D/H) | 600mm/420mm/2350 mm | 600mm/420mm/1750 mm | 600mm/420mm/1950 mm | 600mm/420mm/2150 mm |
| | Net weight | 461Kg | 299Kg | 353Kg | 407Kg |
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C~55°C | -15°C~55°C | -15°C~55°C | -15°C~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional |

| Model | | LC-E2-1035T | LC-E2-1225T | LC-E2-1230T | LC-E2-1235T |
|-----------------------------|---|------------------|------------------|------------------|------------------|
| PV input | Maximum PV input power | 15kW | 18kW | 18kW | 18kW |
| | Maximum PV input voltage | 1000V | 1000V | 1000V | 1000V |
| | MPPT voltage range | 180~850V | 180~850V | 180~850V | 180~850V |
| | MPPT voltage range at full power | 430~850V | 510~850V | 510~850V | 510~850V |
| | Maximum PV input current | 2*13A | 2*13A | 2*13A | 2*13A |
| | PV short circuit current | 2*16A | 2*16A | 2*16A | 2*16A |
| | Number of MPPT / Maximum number of strings in parallel of each MPPT | 2/1 | 2/1 | 2/1 | 2/1 |
| Battery parameters | Input voltage range of battery | 291~409V | 208~292V | 249~350V | 291~409V |
| | Rated voltage of battery pack | 358.4V | 256V | 307.2V | 358.4V |
| | Battery capacity | 5.12kWh*7 | 5.12kWh*5 | 5.12kWh*6 | 5.12kWh*7 |
| | Maximum charge/ discharge current | 50A/50A | 50A/50A | 50A/50A | 50A/50A |
| | Maximum charge / discharge power | 10kW | 12kW | 12kW | 12kW |
| | Battery type | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) |
| | Communication interface | CAN | CAN | CAN | CAN |
| Grid-connected output/input | Rated grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Rated output power | 10kW | 12kW | 12kW | 12kW |
| | Maximum grid-connected output apparent power | 11kVA | 13.2kVA | 13.2kVA | 13.2kVA |
| | Maximum grid-connected output current | 15.9A | 19.1A | 19.1A | 19.1A |

6-15KW Lenercom Residential ESS
User's Manual

| | | | | | |
|----------------------|---|---|---|---|---|
| | Maximum grid-connected input apparent power | 22kVA | 26.4kVA | 26.4kVA | 26.4kVA |
| | Maximum grid-connected input current | 31.9A | 38.2A | 38.2A | 38.2A |
| | Power factor | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap |
| | Total harmonic distortion rate of current | <3% | <3% | <3% | <3% |
| Off-grid output | Rated off-grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated off-grid frequency | 50/60Hz | 50/60Hz | 50/60Hz | 50/60Hz |
| | Maximum off-grid output apparent power | 11kVA | 13.2kVA | 13.2kVA | 13.2kVA |
| | Maximum off-grid output current | 15.9A | 19.1A | 19.1A | 19.1A |
| | Switching duration | <20ms | <20ms | <20ms | <20ms |
| | Total harmonic distortion rate of voltage | <2% | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 97.5% | 97.6% | 97.6% | 97.6% |
| | Maximum efficiency | 98.2% | 98.2% | 98.2% | 98.2% |
| | European efficiency | 97.5% | 97.5% | 97.5% | 97.5% |
| | MPPT efficiency | 99.5% | 99.5% | 99.5% | 99.5% |
| General data | Dimensions (W/D/H) | 600mm/420mm/2350mm | 600mm/420mm/1950mm | 600mm/420mm/2150mm | 600mm/420mm/2350mm |
| | Net weight | 461Kg | 353Kg | 407Kg | 461Kg |
| | IP grade | IP20 | IP20 | IP20 | IP20 |
| | Working temperature | -15°C~55°C | -15°C~55°C | -15°C~55°C | -15°C~55°C |
| | Noise | <35dB | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional |

| Model | | LC-E2-1535T | LC-E2-1540T | LC-E2-1545T |
|--------------------|---|------------------|------------------|---------------|
| PV input | Maximum PV input power | 22.5kW | 22.5kW | 22.5kW |
| | Maximum PV input voltage | 1000V | 1000V | 1000V |
| | MPPT voltage range | 180~850V | 180~850V | 180~850V |
| | MPPT voltage range at full power | 620~850V | 620~850V | 620~850V |
| | Maximum PV input current | 2*13A | 2*13A | 2*13A |
| | PV short circuit current | 2*25A | 2*25A | 2*25A |
| | Number of MPPT / Maximum number of strings in parallel of each MPPT | 2/1 | 2/1 | 2/1 |
| Battery parameters | Input voltage range of battery | 291~409V | 333~467V | 374~525V |
| | Rated voltage of battery pack | 358.4V | 409.6V | 460.8V |
| | Battery capacity | 5.12kWh*7 | 5.12kWh*8 | 5.12kWh*9 |
| | Maximum charge/ discharge current | 50A/50A | 50A/50A | 50A/50A |
| | Maximum charge / discharge power | 15kW | 15kW | 15kW |
| | Battery type | LiFePO4 (LFP) | LiFePO4 (LFP) | LiFePO4 (LFP) |
| | Communication interface | CAN | CAN | CAN |
| Rated grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V | |

| | | | | |
|----------------------|--|---|---|---|
| | Rated grid frequency | 50/60Hz | 50/60Hz | 50/60Hz |
| | Rated output power | 15kW | 15kW | 15kW |
| | Maximum grid-connected output apparent power | 16.5kVA | 16.5kVA | 16.5kVA |
| | Maximum grid-connected output current | 23.8A | 23.8A | 23.8A |
| | Maximum grid-connected input apparent power | 30kVA | 30kVA | 30kVA |
| | Maximum grid-connected input current | 47.6A | 47.6A | 47.6A |
| | Power factor | 0.8ind...0.8cap | 0.8ind...0.8cap | 0.8ind...0.8cap |
| | Total harmonic distortion rate of current | <3% | <3% | <3% |
| Off-grid output | Rated off-grid voltage | 3W+N+PE,230/400V | 3W+N+PE,230/400V | 3W+N+PE,230/400V |
| | Rated off-grid frequency | 50/60Hz | 50/60Hz | 50/60Hz |
| | Maximum off-grid output apparent power | 16.5kVA | 16.5kVA | 16.5kVA |
| | Maximum off-grid output current | 23.8A | 23.8A | 23.8A |
| | Switching duration | <20ms | <20ms | <20ms |
| | Total harmonic distortion rate of voltage | <2% | <2% | <2% |
| Efficiency parameter | Charge/discharge efficiency of battery | 97.8% | 97.8% | 97.8% |
| | Maximum efficiency | 98.5% | 98.5% | 98.5% |
| | European efficiency | 97.6% | 97.6% | 97.6% |
| | MPPT efficiency | 99.5% | 99.5% | 99.5% |
| General data | Dimensions (W/D/H) | 600mm/420mm/2350 mm | 600mm/420mm/2550 mm | 600mm/420mm/2750 mm |
| | Net weight | 463Kg | 517Kg | 571Kg |
| | IP grade | IP20 | IP20 | IP20 |
| | Working temperature | -15°C~55°C | -15°C~55°C | -15°C~55°C |
| | Noise | <35dB | <35dB | <35dB |
| | Display | LCD | LCD | LCD |
| | Communication mode | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional | RS485/CAN/DRM Have 4G/WIFI Optional |

9.3 Table of battery module parameters

| | |
|---------------|------------------------|
| Model | LC-BH512 |
| Battery type | Lithium iron phosphate |
| Capacity | 5.12kWh |
| Rated voltage | 51.2V |

| | |
|---|-------------------|
| Maximum charge/ discharge current | 50A/110A |
| Range of charging temperature | 0°C ~+55°C |
| Range of discharging temperature | -15°C ~+55°C |
| Discharging overcurrent protection | 110A |
| Communication mode | RS485/CAN |
| Dimensions (W/D/H) | 600mm/420mm/200mm |
| Weight | 54kg |
| <p>Prompt: the discharge rate will be attenuated when the temperature is lower than 0 ° C When the temperature is lower than 0 °C, the battery cannot be charged When the temperature is lower than -15°C, the battery cannot be discharged</p> | |

9.4 Dimensions and weight of equipment

| Equipment name | Dimension (mm) | Net weight (kg) |
|---------------------------------|----------------|-----------------|
| 8 -12kW hybrid inverter (W/D/H) | 600*420*600 | 65.5±1 |
| Battery module (W/D/H) | 600*420*200 | 54±1 |
| Base (W/D/H) | 600*420*130 | 17.5±1 |

9.5 Dimensions and weight of packaging

| Packaging | Dimension (mm) | Net weight (kg) |
|--|----------------|-----------------|
| Packing carton of inverter (W/D/H) | 690*450*650 | 10.5 |
| Packing carton of battery module (W/D/H) | 670*455*260 | 8 |
| Packing carton of base (W/D/H) | 660*460*170 | 3 |

10 Transportation

Basic Requirements

- LC-E2 shall be packed and shipped separately.
- Before packing and transportation, the package shall be intact and undamaged, and the product model and identification information shall be clear and complete.

- The product shall not be transported together with inflammable, explosive and other dangerous goods.
- The equipment shall be transported on the pallet with anti-dumping measures to avoid the violent vibration.

11 Storage

Before the assembly of LC-E2, the inverter, battery module and base shall be packed and stored separately. If they are not put into use immediately, the storage shall meet the following requirements:

- Do not remove the outer package of inverter, battery module and base.
- The storage temperature shall be kept at $-20\text{ }^{\circ}\text{C} \sim +60\text{ }^{\circ}\text{C}$, and the recommended temperature is $25\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$; the relative humidity shall be kept at $5\% \text{ RH} \sim 95\% \text{ RH}$.
- The product shall be stored at the clean and dry place to prevent the erosion caused by dust and water vapor.
- Up to 6 layers can be stacked. The equipment shall be stacked carefully to avoid personal injury or equipment damage caused by rollover.
- During the storage, regular check shall be made (it is recommended to check once every three months). If the packages are damaged by insects and rat, the packaging materials shall be replaced in time.
- During the storage period, the battery shall be checked regularly to supplement the power loss caused by self-discharge and keep about 50% of power (it is recommended to check once every 6 months).
- If the storage time of battery is 1 year or more, the battery shall be checked and tested by professionals before put into use.
- If the storage time of inverter is 2 years or more, the battery shall be checked and tested by professionals before put into use.

12 Fault Diagnosis

When you encounter any of the following issues, please refer to the following solutions. If such issue remains unresolved, please consult your local distributor.

| Fault | Fault code | Solution |
|-------------------------|------------|--|
| Discharging overcurrent | 00 29 | (1) Inverter will restart automatically 1min later. (2) Check whether the load size is consistent with the description in the specification (3) Cut off all power switches and power on the whole machine again after the display goes off (4) If the issue remains unsolved, check whether there is a short circuit at the |

| | | |
|--|----------------|---|
| | | load end. |
| Overload | 01 | (1) Check whether the load size is lower than the maximum power of whole machine. (2) Cut off all power switches and power on the whole machine again after the display goes off (3) If the issue remains unsolved, check whether there is a short circuit at the load end. |
| Battery not connected | 02 | (1) Check whether the battery is connected (2) Check the connection wire of battery for the open circuit (3) If the issue remains unresolved, please consult your local distributor |
| Battery undervoltage | 03 04 26 | (1) Check whether the voltage setting range of the battery is compatible with that of the current battery. (2) Check whether the power grid and PV are live. If not, the battery will be automatically charged after power restoration. (3) If the issue remains unresolved, please consult your local distributor |
| Battery overvoltage | 05 27 | (1) Check whether the voltage setting range of the battery is compatible with that of the current battery. (2) Check whether the power grid is cut off. If the power supply is turned off, the power grid will automatically charge the battery after the power restoration. (3) If the issue remains unresolved, please consult your local distributor |
| Battery undervoltage | 06 | (1) Check whether the grid is abnormal (2) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (3) If the issue remains unresolved, please consult your local distributor |
| Grid overvoltage | 07 | (1) Check whether the grid is abnormal (2) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (3) If the issue remains unresolved, please consult your local distributor |
| Low frequency of grid | 08 | (1) Check whether the grid is abnormal (2) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (3) If the issue remains unresolved, please consult your local distributor |
| High frequency of grid | 09 | (1) Check whether the grid is abnormal (2) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (3) If the issue remains unresolved, please consult your local distributor |
| Leakage current exceeding the standard | 10 | (1) Check whether PV panel is short-circuited to ground (2) Check whether the electric leakage to PE at load side. (3) If the issue remains unresolved, please consult your local distributor |
| PV not connected | 11 | (1) Check whether the PV panel is connected to its corresponding port |

| | | |
|--|----------------------|---|
| | | (2) PV switch on the front panel of whole machine is not closed (3) Check whether PV panel is damaged |
| Grid CT inversed | 12 | (1) Check the wiring direction of CT (2) If the issue remains unresolved, please consult your local distributor |
| Low voltage of bus | 13 | (1) Check whether the input mode is correct (2) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (3) If the issue remains unresolved, please consult your local distributor |
| Overvoltage of bus | 14 | (1) Check whether the input mode is correct (2) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (3) If the issue remains unresolved, please consult your local distributor |
| Inverter overcurrent | 15 | (1) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (2) If the issue remains unresolved, please consult your local distributor |
| Charger overcurrent | 16 | (1) Check the battery side for the open circuit (2) Check the settings of charging current (3) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. |
| Voltage oscillation of bus | 17 18 19 20 | (1) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (2) If the issue remains unresolved, please consult your local distributor |
| High ambient temperature | 21 | (1) Check whether the current ambient temperature exceeds the recommended operating temperature. If so, power on the whole machine after powering off it for one hour. (2) If the issue remains unresolved, please consult your local distributor |
| High battery temperature | 23 | (1) Power on the whole machine after powering off it for one hour. (2) If the issue remains unresolved, please consult your local distributor |
| Low battery temperature | 24 | (1) Check the ambient temperature near the battery to see if it meets the specifications. (2) If the issue remains unresolved, please consult your local distributor |
| Large voltage difference of battery monomers | 25 | (1) Carry out continuous charging and discharging on the battery. The specific operation is as follows: disconnect the grid side and the PV side for one hour first, and then turn off the switch on the grid side and the PV side after one hour of discharging, to charge the battery for 1 to 2 cycles, and then the battery voltage will return to normal. (2) If the issue remains unresolved, please consult your local distributor |
| Charging overcurrent | 28 | (1) Check the battery line for short circuit (2) Check the of settings of charging current (3) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. If the issue remains unresolved, please consult your local distributor |

| | | | |
|---------------------------------|----|---|---|
| Soft start failure of bus | 32 | (1) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (2) If the issue remains unresolved, please consult your local distributor | |
| Soft start failure of inverter | 33 | | |
| Short circuit of bus | 34 | | |
| Short circuit of inverter | 35 | | |
| Fault of fan | 36 | | |
| Fault of BUS relay | 38 | | |
| Fault of Grid relay | 39 | | |
| Fault of EPS relay | 40 | | |
| Fault of GFCI | 41 | | |
| Fault of internal CT | 42 | | |
| Fault of off-grid relay | 43 | | |
| System fault | 44 | | |
| Low insulation resistance of PV | 45 | | (1) Check whether PE line is grounded (2) If the issue remains unresolved, please consult your local distributor |
| Short circuit of PV | 37 | | (1) Power off the whole machine, wait for the LCD display to be turned off, and then power it on. (2) If the issue remains unresolved, please consult your local distributor |
| Reversed battery | 43 | (1) Check the anode and cathode wirings are correct (2) If the issue remains unresolved, please consult your local distributor | |

13 Warranty

13.1 Warranty Period

Hunan Lenercom Technology Co., Ltd. (hereinafter referred to as "Lenercom") provides LC-E2 ESS series products (hybrid inverter (referred to as "inverter") + battery module) with warranty services in line with warranty scope and conditions, and the warranty period is 5 years for inverter and 10 years for battery module.

The warranty period is calculated from 1) the first installation date; 2) 3 months from the delivery by Lenercom (whichever comes first).

13.2 Warranty Conditions

LC-E2 products purchased and installed through Lenercom or its authorized partners are within the warranty scope of Lenercom. New, second-hand or refurbished products purchased through other channels are not covered by this warranty.

13.3 Request for Repair

During the warranty period, if the product is operated normally according to the manual, and the product fails or cannot work, the requester can send the Customer Repair Registration Form or provide enough information to Lenercom through call/fax/e-mail to help the after-sales service team complete the warranty repair. [This article is tentative: first understand how to realize it on the computer, register on the website as recommended, and then report the fault directly].

The requester shall provide the following information or documents about the faulty product:

| S/N | Content |
|-----|--|
| 1 | Contact information of requester: including name, company name, telephone number, email, contact address and purchase outlet; |
| 2 | Information of faulty product: including product model, serial number, installation date and fault date (which can be provided by photos); |
| 3 | PV installation information (if any): including the brand, model and quantity of PV system components; |
| 4 | If conditions permit, please provide LCD error information, additional fault/error information, etc.; |
| 5 | Description of product performance before fault; |
| 6 | Provide the PN code. |

If the product fails during the warranty period, Lenercom will handle it in one of the following ways:

- ◎Remote video technical support;
- ◎On-site maintenance by Lenercom or its authorized third party;
- ◎Send it back to Lenercom maintenance center for repair;
- ◎Replace it with a refurbished machine with the latest firmware (if the production of original model has been suspended and there is no stock, Lenercom has the right to provide products with equal value and equal functions for replacement).

Depending on the fault, Lenercom will arrange remote video technical support or on-site inspection to identify the cause. The requester shall ensure that the technical personnel of Lenercom and its authorized third party have the authority and time to conduct on-site inspection and protect their safety. In case that the technical personnel think that the site safety conditions are insufficient, they have the right to refuse access to the site. The requester shall be responsible for the failure of inspection due to negligence in site access conditions, time or safety.

The replaced product or component in return shipment shall be in the original packaging or equivalent packaging. The replacement product will automatically inherit the remaining warranty period. Before the shipper entrusted by Lenercom retrieves the replaced product, the requester shall be responsible for the proper preservation of the product, and the lost product during this period shall be compensated by the requester.

13.4 Faults beyond Warranty Scope

Product faults caused by the following conditions are not covered by the warranty:

- ◎Failure to comply with applicable safety regulations;
- ◎The product is damaged, lost or stolen during transportation;

- ◎ Fault or damage caused by the causes other than product quality;
- ◎ Failure to comply with user manual, maintenance procedures and time intervals, incorrect use or improper storage, operation, debugging or modification of products;
- ◎ Live installation, wiring or incorrect use of tools;
- ◎ Product damage caused by disassemble, repair, process, replacement, installation or commissioning by the distributor or installer not authorized or certified, or due to the negligence or recklessness, intentional behavior of any third party;
- ◎ The service environment of product exceeds the normal temperature (0°C-40°C);
- ◎ Product fault or damage caused by the wrong installation position (for example, the distance from the wall can not meet the installation requirements of the manual, and the outside of box is corroded, dusted or drenched, or the product is exposed to coastal/saline or other corrosive environmental conditions);
- ◎ Product damage due to the risk of installation location (such as the storage place of inflammable and explosive materials, high humidity area (no condensation when the humidity exceeds 85%), and long-term water accumulation area)
- ◎ Product damaged caused by the product accessories or consumables purchased from third parties other than Lenercom or the authorized agency;
- ◎ Battery power loss due to normal loss and long-term idleness for more than 6 months;
- ◎ The requester refuses to provide the information about the installation, commissioning, operation, use environment and fault;
- ◎ Damage caused by force majeure (such as extreme weather, fire, flood, earthquake, lightning strike, lightning, war, etc., including but not limited to the above events);
- ◎ All other environments and behaviors that may damage the normal use of equipment.

13.5 Service after Expiration of Warranty Period

For products beyond the warranty period, Lenercom can still provide related services, but will charge relevant fees to end users, including but not limited to:

- ◎ On-site service fee: including the travel expenses and working hours of technicians who deal with problems on site.
- ◎ Material cost: the cost of replacing materials (including all transportation and management expenses).
- ◎ Labor cost: the labor cost of technicians includes testing, repairing, maintaining, installing (hardware or software) and debugging faulty products.
- ◎ Logistics costs: delivery costs and other related costs, including sending faulty products from users to Lenercom or/and repaired products from Lenercom to the user's location.

13.6 Miscellaneous

The purchase invoice shall be properly kept as the basis for repairing. [Tentative]

Warranty clause is the only express guarantee clause of Lenercom for LC-E2 products without any other express, implied, oral or written warranty.

Warranty cannot be understood as a guarantee of product service life or usability of products of the same model.

During the warranty period, Lenercom shall assume the labor cost of maintenance and testing and the cost of required materials and no other expenses.

Unless otherwise provided in a separate service agreement between Lenercom and the customer, this agreement shall prevail.

13.7 Contact Information

Hunan Lenercom Technology Co., Ltd.

Tel: +86 73188051567

E-mail: service@lenercom.com

Official website: cn.lenercom.com

Address: Building B1, Lugu Innovation and Entrepreneurship Park, Yuelu District, Changsha City, Hunan Province



iOS



Google



Android

Warranty card

Lenercom

PRODUCT WARRANTY CARD

| | |
|-----------------|-------|
| Product Name | _____ |
| Product Model | _____ |
| Production Date | _____ |

Hot-Line: +86 731 85976599

Warranty Card Ordinance _____ **Lenercom**

1. The inverter warranty period is _____ years, and the battery warranty period is _____ years
2. During the warranty period, if there is a problem in normal use according to the manual (as determined by the official staff of the company), free maintenance will be offered.
3. During the warranty period, if the following problems occur, they must be treated as charges
 - 1) Cannot provide this guarantee or provide a valid proof of purchase
 - 2) Damage and malfunction caused by wrong usage or improper self-repair
 - 3) Damages and malfunctions caused by transportation, dropping, and handling after purchase
 - 4) Damage and failure caused by other unavoidable external factors
 - 5) Damage and failure caused by water or other solutions caused by improper use

Lenercom

Lugu Science & Technology Industrial Park, Changsha.

☎ +86 0731-88051567 📠 +86 181 0841 3339

CN.LENERCOM.COM

